

TAIKO NO TATSUJIN

2024 USA Ver.

© BANDAI NAMCO Amusement Inc.

User's Manual

Images in this document may differ from the actual product.

⚠ WARNING

- To ensure safe operation of this game machine, please read this manual before use.
- Keep this manual for future reference.

Game machine specifications and this manual may be changed without notice for improvement.

Introduction

Thank you very much for purchasing "TAIKO NO TATSUJIN 2024 Ver."; referred to as "game machine" hereafter.

The following items are explained in this manual:

- How to safely install, move, transport, operate, service and dispose of this game machine.
- How to make full use of the game machine's functions and operate it correctly.
- How to ensure the safety of players and bystanders.

Contact information regarding this game machine and repair inquiries

- For inquiries regarding repair of this game machine, contact your distributor.

Table of Contents

Introduction	B
1. Safety Precautions - Be sure to read to ensure safe operations -	1
1-1 Levels of Risk.....	1
1-2 Definition of "Technician"	1
1-3 READ FIRST: Critical Safety Precautions.....	2
1-4 Warning Labels Used on This Game Machine.....	3
2. Specifications	5
3. Checking the Package Contents	7
4. Overall Structure (Part Names)	9
5. Installation	12
5-1 Installation Conditions	12
5-1-1 Installation Locations to Avoid	12
5-1-2 Play Zone for the Installed Game Machine.....	13
5-1-3 Necessary Dimensions when Bringing the Game Machine in for Delivery (Such as Doors and Hallways)..	13
6. Operation.....	14
6-1 People Who Should Not Play This Game Machine	14
6-2 Safety Precautions for Playing	14
6-3 Pre-Operation Inspection.....	15
6-3-1 Safety Inspection (Before Power On)	15
6-3-2 Function Inspection (After Power On).....	15
6-4 Playing the Game.....	16
6-4-1 Game Overview.....	16
6-4-2 Bandai Namco Passport (IC Cards)	16
6-4-3 Using Bandai Namco Passport (IC Cards) with This Game Machine.....	16
6-4-4 Code Reader	16
6-4-5 How to Operate.....	16
6-4-6 Rules of the Game.....	17
6-4-7 Types of Symbols.....	18
6-4-8 Levels of Difficulty.....	18
6-4-9 Performance Options	18
6-4-10 "Donder Hiroba" Connected Site	20
6-5 Power Switches and Adjustment Switches	20
6-5-1 Turning On the Power Switch	20
6-5-2 Adjustment Switches	21
(a) Service switch (Red)	21
(b) Test switch	21
(c) Select switch	21
(d) Enter switch (Green)	21
6-6 Test Mode	22

1
2
3
4
5
6
7A
7B
8
9
10

6-6-1	Menu Screens (MENU)	22
6-6-2	Game Cost Settings (COIN OPTIONS)	24
6-6-3	Game Contents Settings (GAME OPTIONS).....	25
	(1) CLOCK/CLOSE TIME SETTING	26
6-6-4	Network Settings (NETWORK OPTIONS).....	28
	(1) NETWORK STATUS.....	29
	(2) LOCAL NETWORK CHECK.....	31
	(3) ACTIVATION	32
6-6-5	Card Reader/Writer Test (CARD READER-WRITER TEST).....	35
	(1) CARD R/W HARDWARE TEST	36
	(2) CARD R/W LAMP TEST	38
	(3) CARD R/W SOUND TEST	39
6-6-6	Switch I/O Test (I/O TEST).....	40
	(2) Adjusting the Taiko Drum Assembly Sensor (TAIKO TEST).....	42
	(3) Lamp Test (LAMP TEST).....	44
	(4) Code Reader Test (CODE READER TEST)	45
6-6-7	Monitor Test (MONITOR TEST)	46
6-6-8	Sound Test (SOUND TEST)	47
6-6-9	Displaying and Initializing the Game Data (BOOKKEEPING).....	49
6-6-10	Other Options (OTHERS).....	50
6-6-11	RELOAD NBLINE POINTS	51
6-6-12	Software Update (SOFTWARE UPDATE).....	52
	(1) Checking the Status of Software Updates	52
6-7	Automatic Software Updates	54
6-8	Cleaning.....	55
	6-8-1 Cleaning the Taiko Drum Assembly.....	55
	6-8-2 Cleaning the Monitor Glass	56
7.	Technician's Manuals - Must be performed by a technician -	57
7A.	Installation and Assembly	57
7A-1	Disassembly	57
	7A-1-1 Removing and Attaching the POP Frame Assembly.....	57
	7A-1-2 Removing and Attaching the Taiko Drum Assembly	59
	7A-1-3 Removing and Attaching the Card Box (QR-EXP) Assembly	60
7A-2	Assembly	61
	7A-2-1 Adjusting the Level Adjusters	61
	7A-2-2 Assembling the POP Frame Assembly	62
	7A-2-3 Attaching the POP Assembly	65
	(1) Attaching the 2024 Ver. Middle POP	65
	(2) Attaching the 2024 Ver. Character POP	67
	(3) Attaching the 2024 Ver. Back POP.....	68
	(4) Attaching the 2024 Ver. Side POP (L) and (R).....	69
7A-3	Connecting the Power Cord and Ground Wire	71
7A-4	Inserting the USB Dongle	72
7A-5	Connecting the LAN Cable.....	74

7A-6	Turning On the Power Switch	76
7A-7	Post-Installation Check	76
7B.	Service	77
7-1	Inspection and Service - Must be performed by a technician -	77
7B-1-1	What to Inspect	77
	(1) Level Adjuster.....	77
	(2) Power Cord Plug.....	77
	(3) Loose Screws (All Components).....	77
7B-2	Troubleshooting.....	78
7B-2-1	General.....	78
7B-2-2	Cabinet Base Assembly.....	79
7B-2-3	Monitor Frame Assembly	79
7B-2-4	Taiko Drum Assembly.....	79
7B-2-5	Card Box (QR-EXP) Assembly	80
7B-2-6	POP Frame Assembly.....	80
7B-2-7	Error Messages.....	81
7B-1-1	Network System Troubleshooting	83
7B-3	Removing, Attaching, and Replacing the Assembly and Parts.....	84
7B-3-1	Cabinet Base Assembly.....	84
	(1) Removing and Attaching the Maintenance Door.....	84
	(2) Replacing the Game PC Board.....	86
	(3) Removing and Attaching the Regulator Base.....	88
	(4) Replacing the AMP PC Board	90
	(5) Replacing the SIF 2 PC Board	91
	(6) Replacing the USIO (T) PC Board.....	92
	(7) Replacing the Switching Regulator	93
	(8) Replacing the Drumsticks.....	94
	(9) Replacing the Drumstick Bags.....	96
7B-3-2	Monitor Frame Assembly	97
	(1) Replacing the LED Lights (Upper Lights)	97
	(2) Replacing the LED Lights (side)	99
	(3) Removing and Attaching the Monitor Frame Covers (A) and (B)	101
	(4) Replacing the LCD Monitor	102
	(5) Replacing the Monitor Glass	104
7B-3-3	Taiko Drum Assembly.....	105
	(1) Replacing the Pad Mask	105
	(2) Replacing the Sensor	107
	[For Pad]	108
	[For Rim]	109
7B-3-4	Card Box (QR-EXP) Assembly	110
	(1) Replacing the Card Reader/Writer.....	110
	(2) Replacing the LED tape	111
	(3) Replacing the Code Reader	113
7B-3-5	POP Frame Assembly.....	114

(1) Replacing the LED Lamps.....	114
(2) Replacing the LED Lights (POP light).....	115
8. Disposal	117
9. Parts List.....	118
9-1 Cabinet Assembly (1).....	118
9-2 Card Box (QR-EXP) Assembly	120
9-3 POP Frame Assembly	121
9-4 POP Assembly	122
9-5 Cord Box Assembly	123
9-6 Regulator Assembly	124
9-7 Other Items	125
10. Wiring Diagram.....	126

1. Safety Precautions - Be sure to read to ensure safe operations -


Instructions for the Owner

If someone besides yourself will be installing, moving, transporting, operating, servicing, or disposing of this game machine, ensure that they read the relevant sections of this manual carefully beforehand and observe the precautions.

1-1 Levels of Risk

The safety and property damage precautions on the game machine labels and in this manual are classified by their risk level, as follows:

 **WARNING** :Failure to avoid these risks may result in death or serious injury.

 **CAUTION** :Failure to avoid these risks may result in injury or damage to other property.

Functionality-related notes that are not related to safety are indicated with the following symbol.

 **NOTICE** :Information about product functions or protection.

1-2 Definition of “Technician”

This manual is designed for arcade personnel. However, the sections marked “Must be performed by a technician” in the Table of Contents are written for technicians. These tasks must be performed by technicians only.

Technician: A person involved in design, manufacture, inspection or maintenance service at an amusement (AM) device manufacturer; or a person routinely involved in the service or management (such as repair) of amusement devices, who also has specialized knowledge of electricity, electronics or mechanical engineering equivalent to or higher than a technical high school graduate.

1-3 READ FIRST: Critical Safety Precautions

If an abnormality occurs with this game machine, turn the power switch off immediately to stop operations.

Then, be sure to disconnect the power cord plug from the outlet. Operating the game machine while the abnormality persists may result in a fire or accident.

Dust accumulating on the power cord plug may result in a fire. Inspect the plug regularly and remove any dust.

Fully insert the power cord plug into the outlet. Poor contact may generate heat and result in a fire or burns.

To ensure safe use of the game machine, be sure to perform the pre-operation inspection

(see P-15 □6-3 Pre-Operation Inspection

Check the following items before opening the game arcade. If any abnormalities are detected, take

necessary measures by referencing P- □7B-2 Troubleshooting□.□) and service

(see P-77 □7B. Service□) mentioned in this manual. Omitting these inspections or service may result in an accident.

Damage to the power cord may result in a fire, electric shock or short circuiting. Be sure to observe the following:

Keep the power cord away from heating devices.

Do not twist the power cord.

Do not forcibly bend the power cord.

Do not alter the power cord.

Do not bundle the power cord.

Do not pull the power cord (always unplug by holding the plug and not the power cord).

Do not place objects on the power cord.

Do not allow the power cord to be caught between the game machine and other devices or the wall.

Do not do anything else that might damage the power cord.

Do not expose the power cord or power cord plug to water. Doing so may result in electric shock or short circuiting.

Do not touch the power cord plug with wet hands. Doing so may result in electric shock.

The power capacity of this game machine is 220 VAC, with a maximum current consumption of 1.5 A. To prevent malfunction of the game machine and fire and electric shock, use indoor wiring that conforms to these power supply specifications.

Use with a power supply voltage range of 220 VAC ± 10 %. Using a voltage outside this range may result in malfunction of the game machine, fire, or electric shock. However, to ensure that the game machine operates in the optimum condition, keep the voltage at 220 VAC as much as possible.


Use the consumables and service parts (including screws) that are specified. To order parts, contact your distributor.

Do not modify the game machine without permission. Also, do not perform any operations that are not described in this manual. Modifying the game machine may result in an unexpected accident.

If you decide to relocate this game machine, be sure to include this manual with the game machine.

1-4 Warning Labels Used on This Game Machine

- The warning labels attached to this game machine contain important information to ensure safety. Be sure to observe the following:
- Ensure that the warning labels attached to the game machine are always clearly visible by installing the game machine in an appropriate location with ample illumination, and by keeping the labels clean at all times. Also, make sure that the labels are not hidden by other game machines or objects.
- Do not remove or alter the warning labels.
- If a warning label becomes excessively dirty or damaged, replace it with a new one. To order warning labels, contact your distributor.



1

2

3

4

5

6


7A


7B


8

9

10


 CAUTION 注意	<ul style="list-style-type: none">●Please beware if you have ever suffered any side effects when playing video games with flashing screens or are concerned that you might be in danger of doing so, please take care when playing the game.●If you feel unwell, please stop playing and take a rest.●Be careful that all areas that you might move into are clear while playing.
<small>8301520500</small>	

 WARNING 警告
<p>To avoid an electrical shock and/or injury, be sure that the power is turned off before opening the service door.</p> <p>Only qualified personnel should attempt to service the game.</p>
<small>8301412201</small>



2. Specifications

- (1) Rated Power Supply : 120 VAC \pm 10% (60 Hz)
- (2) Maximum power consumption : 360 W
- (3) Maximum current consumption : 3A
- (4) Monitor : 32-inch LCD monitor
- (5) Dimensions
When shipped : Width (W) 50in (D) 37.79in x height (H) 80.70in



1

2

3

4

5

6

7A

7B

8

9

10

Specifications


Test Mode

Troubleshooting

2. Specifications

When installed :Width (W) 63.77in x depth (D) 37.79in x height (H) 90.55in
(including side POPs [AL, AR])

POP frame assembly :Width (W) 33.07in x depth (D) 20.66in x height (H) 31.49in



(7) Weight

When installed	Net weight	: 463 lb
When separated	Cabinet base assembly	: 231 lb
	Monitor frame assembly	: 143 lb
	Taiko drum assembly	: 30 lb x 2
	Card box assembly	: 11 lb
	POP frame assembly	: 18 lb



3. Checking the Package Contents

The following items are included when this game machine is shipped.

NOTICE

- Make sure that all the items below are contained in the product package.
- If any items are missing, contact your distributor.

Main unit



Coin lock key
x2





USB dongle



Cam lock key
x2



LAN cable (10 m)



Assembly screw set


Torx bolt (M5 x 12, silver)
x15



Torx bolt (M5 x 12, black)
x8



Flat washers (Φ5.5 x 25 x 11.2)
x15



Inside cash box

- 1
- 2
- 3
- 4
- 5
- 6
- 7A
- 7B
- 8
- 9
- 10

Checking the Package Contents

Test Mode

Troubleshooting

3. Checking the Package Contents

POP Assembly Container

width (W) 63in x depth (D) 22in x height (H) 3in; weight: 15lb


2024 Ver. middle POP
x1




2024 Ver. character POP
x1



2024 Ver. side POP (L)
x1



2024 Ver. side POP (R)
x1





Middle POP reinforcement
x2





2024 Ver. poster (EXP)
x1



Introduction Sheet (HOW TO PLAY) A4 Set
2024 Ver. (set of 4 sheets)
x1



4. Overall Structure (Part Names)






- 1
- 2
- 3
- 4
- 5
- 6
- 7A
- 7B
- 8
- 9
- 10

Overall Structure (Part Names)


- Test Mode
- Troubleshooting

4. Overall Structure (Part Names)





Arrow A (inside coin door)



Arrow B (inside cord box)

- 1
- 2
- 3
- 4
- 5
- 6
- 7A
- 7B
- 8
- 9
- 10

Overall Structure (Part Names)

Test Mode

Troubleshooting

5. Installation

- Install the game machine according to the instructions in this manual. Failure to follow these instructions may result in a fire, electric shock, injury or malfunction.
- Fully insert the power cord plug into the outlet. Poor contact may generate heat and result in a fire or burns.
- Ensure that the ground wire is connected. Failure to connect the ground wire may result in electric shock in the event of a short circuit. (See P-71 [7A-3 Connecting the Power Cord and Ground Wire] .)
- Be sure to install the game machine securely by using the level adjusters. Failure to secure the game machine may result in an accident or injury. (See P-61 [7A-2-1 Adjusting the Level Adjusters] .)

5-1 Installation Conditions

5-1-1 Installation Locations to Avoid


- This game machine is designed for indoor use. Never install the game machine outdoors or in the following locations:
 - A location exposed to direct sunlight
 - A location exposed to rain or water leaks
 - A damp location
 - A dusty location
 - A location close to heating devices
 - A high-temperature location
 - An extremely cold location
 - A location exposed to condensation caused by temperature differences
 - A location that obstructs an emergency exit, or a location containing fire extinguishing equipment
 - An unstable location or a location exposed to vibration

5-1-2 Play Zone for the Installed Game Machine

⚠ CAUTION

Create a play zone as shown in the diagram below, so that players, bystanders, and passersby do not bump into each other.

When installing the game machine, create a play zone like the one shown in the diagram below. Be sure that this play zone is made available, as it is also required for maintenance work.



5-1-3 Necessary Dimensions when Bringing the Game Machine in for Delivery (Such as Doors and Hallways)

A delivery route sufficiently larger than the game machine height and width must be secured.

The dimensions of this game machine are as follows:

When shipped: width (W) 50in x depth (D) 38in x height (H) 81in ; weight: 308 lb

Refer to these dimensions, and ensure that the game machine can be delivered without any major issues.

The game machine can also be separated as shown below, in case the dimensions of the delivery route make it necessary.

- Cabinet assembly: width (W) 50in x depth (D) 37in x height (H) 48in ; weight: 308 lb

- POP frame assembly

: width (W) 33in x depth (D) 21in x height (H) 31in ; weight: 17 lb

Refer to P-57 7A-1 Disassembly for instructions on separating the game machine components.

1

2

3

4

5

6

7A

7B

8

9

10

Installation

Test Mode

Troubleshooting

6. Operation

WARNING

- If an abnormality occurs with this game machine, turn the power switch off immediately to stop operations. Then, be sure to disconnect the power cord plug from the outlet. Operating the game machine while the abnormality persists may result in a fire or accident.
- Dust accumulating on the power cord plug may result in a fire. Inspect the plug regularly and remove any dust.
- Fully insert the power cord plug into the outlet. Poor contact may generate heat and result in a fire or burns.
- Before starting operations, make sure that the game machine has been installed according to the descriptions and specified procedures shown in this manual (see P-12 ¶5. Installation¶#.) A game machine that has not been correctly installed may result in an unexpected accident.
- The warning labels attached to this game machine contain important information to ensure safety. Be sure to observe the following: (For where to apply the warning labels, see P-3 ¶1-4 Warning Labels Used on This Game Machine¶#.)
- Ensure that the warning labels attached to the game machine are always clearly visible by installing the game machine in an appropriate location with ample illumination, and by keeping the labels clean at all times. Also, make sure that the labels are not hidden by other game machines or objects. Do not remove or alter the warning labels.
- If a warning label becomes excessively dirty or damaged, replace it with a new one. To order warning labels, contact your distributor.
- To ensure safe use of the game machine, be sure to perform the pre-operation inspection (see P-15 ¶6-3 Pre-Operation Inspection
Check the following items before opening the game arcade. If any abnormalities are detected, take necessary measures by referencing P- ¶7B-2 Troubleshooting¶#) and service (see P-77 ¶7B. Service¶#) mentioned in this manual. Omitting these inspections or service may result in an accident.
- Failure to clean dust accumulated inside the game machine for a long period of time may result in a fire or malfunction. Regularly clean the inside of the game machine after purchase.

6-1 People Who Should Not Play This Game Machine

WARNING

- In order to ensure players' safety, you should advise a person playing the game to quit if he/she falls under any of the following categories:
- His/her behavior contravenes the points highlighted by the warning labels on the game machine.

6-2 Safety Precautions for Playing

WARNING

- If this game machine is installed in a location where young children play the games, be sure to prepare a safe step stool. A child may be injured if he/she tries to climb the game machine.

CAUTION

- If a player starts feeling sick as a result of image-related stimuli or game lights, you should advise him/her to stop playing and rest.
- In rare cases, stimulation by lights or video images may cause the player to have a seizure or lose consciousness. If this happens, the player must obtain medical assistance immediately. If a preschool child is playing the game, be sure to advise their parent(s) to monitor their child when they are playing the game.

6-3 Pre-Operation Inspection

Check the following items before opening the game arcade. If any abnormalities are detected, take necessary measures by referencing P-78 [7B-2 Troubleshooting].

6-3-1 Safety Inspection (Before Power On)

- Operating the game machine with parts that are damaged, broken, or deteriorated, or with an incomplete installation may result in injury to the player or nearby individuals. If you notice an abnormality, replace it promptly. To purchase parts, contact your distributor.
- Check the following locations before opening the game arcade. These checkups are critical to prevent accidents and personal injuries.

- (1) Are the warning labels legible?
(See P-3 [1-4 Warning Labels Used on This Game Machine].)
- (2) Is the specified play zone provided?
(See P-13 [5-1-2 Play Zone for the Installed Game Machine].)
- (3) Are all level adjusters adjusted correctly?
(See P-61 [7A-2-1 Adjusting the Level Adjusters].)
- (4) Are the drumsticks splinter- and damage-free, and are the straps secure?
- (5) Is the rubber portion of the taiko drum assembly free of cuts and damage?
- (6) Is the coin slot tightly secured and free of damage?
- (7) Is the coin slot free of foreign objects?
- (8) Are the power code plug and power input part of the power cord appropriately and firmly connected?
- (9) Are the power code plug and outlet free of dust?

Check the following items after turning the power switch on. If any abnormalities are detected, turn the power switch off immediately and stop operation. Then, disconnect the power code plug from the outlet and contact the distributor.

- (10) Is any part of the power cord or plug abnormally hot?
- (11) Does touching the game machine impart a tingling electric shock?
- (12) Are there any burning smells, abnormal noises or vibrations?
- (13) Are there any other abnormalities or malfunctions?

6-3-2 Function Inspection (After Power On)

- (1) Is the screen displayed on the LCD monitor?
(See P-46 [6-6-7 Monitor Test (MONITOR TEST)].)
- (2) Are the LED lamp and LED light turned on?
(See P-44 "7-6-6 (3) LAMP TEST".)
- (3) Is sound produced normally?
(See P-47 [6-6-8 Sound Test (SOUND TEST)].)
- (4) When the rim and surface of the taiko drum assembly are hit, are the correct impacts being input and sounds output?
(See P-42 "7-6-6 (2) Adjusting the Taiko Drum Assembly Sensor (TAIKO TEST)".)
- (5) Does the card reader/writer operate correctly?
(See P-35 6-6-5 Card Reader/Writer Test (CARD READER-WRITER TEST) .)
- (6) Is the communication function operating correctly?
(See P-29 "7-6-4 (1) NETWORK STATUS" and P-31 "7-6-4 (2) LOCAL NETWORK CHECK".)

6-4 Playing the Game

6-4-1 Game Overview

This game machine is designed to be played by one or two players (jointly) to enable them to enjoy creating a musical performance by hitting the taiko-shaped (drum-shaped) input device using the drumsticks in time with the music.

You can play so many songs, including new additions, on this game machine.

6-4-2 Bandai Namco Passport (IC Cards)

Bandai Namco Passport is the IC card that can be commonly used on game machines that support this card.

You can start playing this game by touching the BANAPASSPORT card-enabled card reader/writer (referred to as "card reader/writer") on this game machine.

Registering a Bandai Namco Passport with the Bandai Namco Passport site allows players to migrate data as desired if they lose their card.

For details on the Bandai Namco Passport, refer to the following website.

Bandai Namco Passport website
<https://banapass.net/>

6-4-3 Using Bandai Namco Passport (IC Cards) with This Game Machine

You can save the result of this game by using a Bandai Namco Passport (referred to as "IC card, etc.").

Playing the game by using the IC card etc. enables players to gain "**ごほうび**" (**Reward**) (such as additional music and costumes for dressing up cartoon characters) in addition to having their scores recorded.

Players can gain "**ごほうび**" (**Reward**) by collecting points that accumulate by playing the game using the IC card etc. as well as playing the game under specific conditions.

6-4-4 Code Reader

This will be used in various campaigns as well as for functions for convenient gameplay.

6-4-5 How to Operate

A player hits the drum-shaped input device using the drumsticks in time with the music. Hitting the drum surface produces a "**ドン (bam)**" sound and hitting the rim produces a "**カツ (biff)**" sound. During the game, the drum surface and rim are used as a musical instrument. At other times, they are used for selection and confirmation purposes. Hit the left or right rim to make a selection, and hit the surface to enter the selection.

6-4-6 Rules of the Game

- 1** Insert a coin or touch the card reader/writer with the IC card, etc. to turn the entry reception screen on. Hit the surface of the drum on the left-hand side (1P) or right-hand side (2P). You will play the game using the taiko drum you have initially selected. If you do not insert the coin during the set entry period, your entry will be invalidated.
- 2** If you and another player play the game together, hit the surfaces of both the right and left taiko drums. A second person can register to play until the first sound track has been selected.
- 3** You can dress up the game character during entry. When using the IC card etc., you can dress up the game character using a costume you
- 4** already have.
- 5** Select the genre and music. Hit the left or right rim to change the selected genre. Hitting the drum surface displays the music titles. Hit the left or right rim to change the selected song. Select **"あそびかた説明" (How to Play the Game)** to display the operating procedure. (Hit the rim five times to cancel the explanation and restore the music selection window.) Hit the drum surface to confirm the currently-selected music.
- 6** Select the difficulty level. Hit the left or right rim to change the selected level of difficulty. When two players are playing the game at the same time, each player can select the desired difficulty level independently. Hit the drum surface to confirm the currently-selected difficulty level and start the game.
- 7** When using an IC card, etc., before confirming the difficulty level, a player can change the performance options that are used during the game.
- 8** The music is played and the symbols flow across the screen from right to left. Hit the taiko drum when the symbol overlaps with the round frame on the left-hand side of the screen. A player's score and **"魂ゲージ" (Soul gauge)** level increase depending on how many times they hit the correct position on the taiko drum at the correct time. Results are announced when each stage is completed
- 9** When a single soundtrack is set (1 stage)] Your game is over at this point.
- 10** [When two or more soundtrack are set (2 stages or more)] You can continue the game for the number of songs remaining. When the set numbers are reached, the game ends even if the quota is reached.
- 11** When the IC card, etc. are used, the player can get a point and **"ごほうび" (Reward)** according to the result of play.

1

2

3

4

5

6

7A

7B

8

9

10

Operation

Test Mode

Troubleshooting

6-4-7 Types of Symbols

赤い音符 (Red symbol) Hit the surface of the taiko drum.

青い音符 (Blue symbol) Hit the rim of the taiko drum.

黄色い音符 (Yellow symbol) Do a Drum Roll on the surface or the rim.

赤い大音符 (Big red symbol) Hit the surface of the taiko drum strongly.

青い大音符 (Big blue symbol) Hit the rim of the taiko drum strongly.

黄色い大音符 (Big yellow symbol) Hit the surface or rim of the taiko drum strongly.

手をつないでいる赤い音符 (Hand-holding red symbol) Hit the surface of the taiko drum. A performance will become more impressive when two players hit the taiko drums together.

手をつないでいる青い音符 (Hand-holding blue symbol) Hit the rim of the taiko drum. A performance will become more impressive when two players hit the taiko drums together.

風船型の音符 (Balloon-shaped symbol) Do a Drum Roll on the surface by the designated number of times.

くす玉型の音符 (Decorative paper ball symbol) Do a Drum Roll on the surface by the designated number of times.

6-4-8 Levels of Difficulty

The following four difficulty levels are available.

"かんたん" (Easy) The musical scores are simple for beginners.

"ふつう" (Normal) The musical scores are for players who are used to playing the taiko drum.

"むずかしい" (Hard) The musical scores are complicated and fairly difficult to play for players who want to master this game.

"おに" (Extreme) (To select it, hit the right-hand side of the rim ten times while **"むずかしい" (Hard)** is displayed.)

These are most difficult musical scores prepared for players who aim to become masters or star performers of the game.

6-4-9 Performance Options

The player(s) can specify any of the following performance options when using an IC card, etc.

A player can specify different performance options redundantly.

(1) 音符のはやさ (Symbol flow speed)

Set the speed at which the symbols flow during gameplay.

Set 1.0 to 2.0 in increments of 0.1, and set 2.5 to 4.0 in increments of 0.5.

(2) ドロン (Vanish)

- **しない (No)** Symbols are displayed as usual during the performance.

- **する (Yes)** Symbols are hidden during the performance. The characters ("**ドン(bam)**" and "**カッ (biff)**" sounds) are displayed and the timing for hitting the taiko drum remains the same.

(3) あべこべ (Inverse)

- **しない (No)**

Symbols are displayed as usual during the performance.

- **する (Yes)**

Although the flow speed of the symbols is normal, blue symbols appear at a point in time when red symbols should be displayed, and vice versa.

Symbols for repeated hitting remain the same.

(4) ランダム (Random)

- **しない (No)**

Symbols are displayed as usual during the performance.

- **きまぐれ (Whimsical)**

Although the flow speed of the symbols remains the same, about 20 % of the red and blue symbols are randomly interchanged with each other.

Symbols for repeated hitting remain the same.

- **でたらめ (Messy)**

Although the flow speed of the symbols remains the same, about 50 % of the red and blue symbols are randomly interchanged with each other.

Symbols for repeated hitting remain the same.

(5) ボイス (Voice)

- **あり (On)**

A voice is played back during gameplay.

- **なし (Off)**

A voice is not played back during gameplay.

(6) 音色 (Sound color)

The color of sounds played when the taiko drum is hit during gameplay changes.

(7) 音符位置調整 (Symbol position adjustment)

Adjust the position of "良" (**Good**) displayed when the taiko drum is hit.

(8) 演奏スキップ (Skip Song)

- **しない (No)**

No change.

- **する (Yes)**

During gameplay, hit the rim of the taiko drum alternately 10 times to stop the Song.

1

2

3

4

5

6

7A

7B

8

9

10

Operation

Test Mode

Troubleshooting

6-4-10 "Donder Hiroba" Connected Site

The following services are available when accessing the "Donder Hiroba" connected site from a computer or smartphone after gameplay with an IC card.

- Browse ranking of scores by songs and level of difficulty (all of Japan, by prefecture).
- Browse your gameplay history.
- Customize your character. (Change costume, color or name.)
- Send and receive challenges with another player to compete for points.
- Hold and participate in competitions with multiple players to compete for points.

For more details, see the "Donder Hiroba" connected site.

<https://donderhiroba.jp/>

•Notes

*You must register to use "Donder Hiroba" Registration is free.

*The communication fee for using the site is separate.

*This service may not be available depending on your device.

*Service may stop temporarily for server maintenance and other issues. In addition, the contents and their configuration may change or be terminated without notice. Thank you for your understanding.

*The name and services provided by the connected site may change without notice.

*Access to the connected site may vary depending on your device.

*The service usage in "Donder Hiroba" reflects the gameplay results of the latest version. Gameplay results of older versions are not reflected.

6-5 Power Switches and Adjustment Switches

6-5-1 Turning On the Power Switch


- 1** Turn on the power switch located at the rear bottom side of the cabinet base assembly.

NOTICE

- Do not turn the power switch on or off unless it is necessary. Not observing this can cause machine failure.
- When turning the power switch on or off, wait a minimum of 30 seconds after the preceding on or off operation.

6-5-2 Adjustment Switches

Open the coin door using the coin lock key to find the adjustment switches.



(a) Service switch (Red)

Loosen the wing bolt (M3 x 10), slide the service switch cover aside and press it.

Pressing this switch allows you to increase the number of credits without operating the coin counter.

(b) Test switch

Turn this switch on to display the test mode screen.

The test mode is used to set the game fees and test each component.

(c) Select switch

Push this switch up and down in the test mode to select the desired item.

(d) Enter switch (Green)

After selecting the desired item using the select switch, press this switch to confirm and execute the selected items.

1

2

3

4

5

6

7A

7B

8

9

10

Operation


Test Mode

Troubleshooting

6-6 Test Mode

6-6-1 Menu Screens (MENU)

- 1** Use the coin lock key to open the coin door. When the Test switch is set to ON, the "MENU" screen appears.
- 2** Flip the Select switch up or down to select the items. The selected item blinks red.
- 3** Press the Enter switch to select the item.
- 4** After finishing the adjustment, select "EXIT" and press the Enter switch. The display returns to the "MENU" screen.
- 5** After finishing all the adjustments, set the Test switch to OFF. The display returns to the game screen.



"MENU" screen

Item	Description
(a) COIN OPTIONS	Set the game cost, etc. See P-24 "6-6-2 Game Cost Settings (COIN OPTIONS)".
(b) GAME OPTIONS	Set the game contents. See P-25 "6-6-3 Game Contents Settings (GAME OPTIONS)".
(c) NETWORK OPTIONS	Set the network settings. See P-28 "6-6-4 Network Settings (NETWORK OPTIONS)".
(d) CARD READER-WRITER TEST	Check the operation of the card reader/writer. See P-35 "6-6-5 Card Reader/Writer Test (CARD READER-WRITER TEST)".
(e) I/O TEST	Test the input/output, etc. of the switches, lamps, and code reader. See P-40 "6-6-6 Switch I/O Test (I/O TEST)".
(f) MONITOR TEST	Check the monitor status. See P-46 "6-6-7 Monitor Test (MONITOR TEST)".
(g) SOUND TEST	Adjust the volume, etc. See P-47 "6-6-8 Sound Test (SOUND TEST)".
(h) BOOKKEEPING	Check the game data. See P-49 "6-6-9 Displaying and Initializing the Game Data (BOOKKEEPING)".
(i) OTHERS	Initialize the backup memory, etc. See P-50 "6-6-10 Other Options (OTHERS)".
(j) RELOAD NBLINE POINTS	Check the NBLINE POINTS. See P-51 "6-6-11 RELOAD NBLINE POINTS".
(k) SOFTWARE UPDATE	Update the software. See P-52 "6-6-12 Software Update (SOFTWARE UPDATE)".
(l) LAST GAME STATUS	The play conditions immediately before turning on the Test switch can be checked. (Memory is reset when the power switch is turned off or the test switch is turned off.) LEFT CREDIT: Unused credit count USE CREDIT: Credit count used by the player during the game (from the start to the finish of the game)

1

2

3

4

5

6

7A

7B

8

9

10


Operation

Test Mode

Troubleshooting

6-6-2 Game Cost Settings (COIN OPTIONS)

- 1** In the "MENU" screen, select "COIN OPTIONS", and press the Enter switch. The "COIN OPTIONS" screen appears.
- 2** Flip the Select switch up or down to select the items. The selected item blinks red.
- 3** Press the Enter switch. The value of the selected item blinks red. Flip the Select switch up or down to change the setting. The setting is shown in yellow once it is changed (the standard setting is shown in green).
- 4** Press the Enter switch again to select another item.
- 5** Select "EXIT" and press the Enter switch to return to the "MENU" screen.




"COIN OPTIONS" screen

Item	Description	Setting	Initial setting
(a) COIN VALUE	"Credit" count per coin is displayed.	1 CREDIT(S) to 9 CREDIT(S)	1
(b) 1P GAME COST	Game cost setting for the 1st player (Setting of "credit" count required to play one game)	1 CREDIT(S) to 19 CREDIT(S)	2
(c) 2P GAME COST	Game cost setting for the 2nd player (Setting of "credit" count required to play one game)	1 CREDIT(S) to 19 CREDIT(S)	2
(d) FREE PLAY	Free play setting	OFF ON	OFF

6-6-3 Game Contents Settings (GAME OPTIONS)

- 1** In the "MENU" screen, select "GAME OPTIONS", and press the Enter switch. The "GAME OPTIONS" screen appears.
- 2** Flip the Select switch up or down to select the items. The selected item blinks red.
- 3** Press the Enter switch. The value of the selected item blinks red. Flip the Select switch up or down to change the setting. The setting is shown in yellow once it is changed (the standard setting is shown in green).
- 4** Press the Enter switch again to select another item.
- 5** Select "EXIT" and press the Enter switch to return to the "MENU" screen.



"GAME OPTIONS" screen

Item	Description	Setting	Initial setting
(a) NUMBER OF STAGES	Number of stages (songs) that can be played per game	1 STAGE(S) to 4 STAGE(S)	2 STAGE(S)
(b) CLOSE TIME SETTING	Set the shop closing time. See P-26 "7-6-3 (1) CLOSE TIME SETTING".	-	-

1

2

3

4

5

6

7A

7B

8

9

10

Operation

Test Mode


Troubleshooting

(1) CLOCK/CLOSE TIME SETTING

Set the shop closing time.

From 30 minutes before the set time, the IC card, etc. cannot be used for new games. The setting can be switched between setting the same time for every day and different times for each day of the week.

- 1** In the "GAME OPTIONS" screen, select "CLOCK/ CLOSE TIME SETTING", and press the Enter switch. The "CLOCK/ CLOSE TIME SETTING" screen appears.
- 2** Flip the Select switch up or down to select the items. The selected item blinks red.
- 3** Press the Enter switch. The value of the selected item blinks red. Flip the Select switch up or down to change the setting. The setting is shown in yellow once it is changed (the standard setting is shown in green).
- 4** If the value of "SCHEDULE TYPE" is set to "WEEK" or "DAY", the selected item switches from "HOUR" to "MIN" (if set to "WEEK", it switches from "MIN" to "HOUR" of the next day) every time the Enter switch is pressed.
- 5** If the value of "SCHEDULE TYPE" is set to "OFF" or if the last item "MIN" is selected, press the Enter switch again to select another item.

**"CLOCK/CLOSE TIME SETTING" screen (1)**

* If "SCHEDULE TYPE" is set to "WEEK":

Item	Description	Setting	Initial setting
(a) SCHEDULE TYPE	Set whether to perform the shop closing process. If you choose to execute this process, set whether to execute it on a specific day of the week or daily at a specified time.	WEEK (Set it for a specific day of the week) DAY (Set it for daily at a specified time.) OFF (Do not perform the shop closing process.)	WEEK
(b) HOUR	Set "hour" of the shop closing time. If "ALL" is set, the shop closing process is not performed.	19 to 26 ALL	24
(c) MIN	Set "minute" of the shop closing time. If "HOUR" is set to "ALL", this item and the value are not displayed.	00 to 55 (5-minute increments)	00

```

          CLOCK/CLOSE TIME SETTING
          [DEFAULT IN GREEN]
CLOCK  2021/04/01 THU 10:00:00

CLOSE TIME SETTING
SCHEDULE TYPE DAY
          HOUR:24 MIN:00

EXIT
          SELECT SW:CHOOSE  ENTER SW:ENTER

```

"CLOCK/CLOSE TIME SETTING" screen (2)

*** If "SCHEDULE TYPE" is set to "DAY":**

- 6** Select "EXIT" and press the Enter switch to return to the "GAME OPTIONS" screen.

1

2

3

4

5

6

7A

7B

8

9

10

Operation


Test Mode

Troubleshooting

6-6-4 Network Settings (NETWORK OPTIONS)

Perform a network test and check the network status.

- 1** In the "MENU" screen, select "NETWORK OPTIONS", and press the Enter switch. The "NETWORK OPTIONS" screen appears.
- 2** Flip the Select switch up or down to select the items. Press the Enter switch to enter the item.
- 3** Flip the select switch up and down to select "EXIT" and press the Enter switch to return to the "MENU" screen.



"NETWORK OPTIONS" screen

Item	Description
(a) NETWORK STATUS	Check the network status. See P-29 "6-6-4 (1) NETWORK STATUS".
(b) LOCAL NETWORK CHECK	Check the network status in the shop. See P-31 "6-6-4 (2) LOCAL NETWORK CHECK".
(c) ACTIVATION	Check the status of the housing signature information, and perform activation. See P-32 "6-6-4 (3) ACTIVATION".

(1) NETWORK STATUS

Check the network status related to NBLINE and check the IP address.

- 1** From the "NETWORK OPTIONS" screen, select "NETWORK STATUS" and press the Enter switch. The "NETWORK STATUS" screen appears.

NETWORK STATUS	
(a) →	NBLINE PCB ID ABDN-0999999
(b) →	GAME VERSION 1.00
(c) →	ALL.Net LICENSE OK
(d) →	GAME SERVER LINK OK
(e) →	IP ADDRESS 000.000.000.000
(f) →	SUBNETMASK 000.000.000.000
(g) →	GATEWAY 000.000.000.000
(h) →	TENPO ROUTER 000.000.000.000
(i) →	PRIMARY DNS 000.000.000.000
(j) →	SECONDARY DNS 000.000.000.000
(k) →	NBLINE SHOP NAME Taiwan 001*
EXIT	
SELECT SW: CHOOSE ENTER SW: ENTER	

* Registered store name

"NETWORK STATUS" screen

1

2

3

4

5

6

7A

7B

8

9

10

Operation

Test Mode

Troubleshooting

6. Operation

Item	Description
(a) NBLINE PCB ID	Displays the network ID.
(b) GAME VERSION	Displays the game version.
(c) NBLINE LICENSE	Displays the NBLINE authentication result. Authentication completed: OK Authentication failed: Error details are displayed. (See P-82 "7B-2-8 Network System Troubleshooting".)
(d) GAME SERVER	Displays the connection state to the game server. Connection completed: LINK OK Connection failed: Error details are displayed. (See P-82 "7B-2-8 Network System Troubleshooting".)
(e) IP ADDRESS	Displays the IP address of the game machine. *
(f) SUBNETMASK	Displays the SUBNETMASK setting value. *
(g) GATEWAY	Displays the IP address of the gateway. *
(h) TENPO ROUTER	Displays the IP address of the shop router. *
(i) PRIMARY DNS	Displays the IP address of the primary DNS. *
(j) SECONDARY DNS	Displays the IP address of the secondary DNS. *
(k) NBLINE SHOP NAME	Displays the shop name that was obtained during the NBLINE authentication process.


* If this is not obtained, the set value "****.***.***.***" is displayed.

- 2** Press the Enter switch to return to the "NETWORK OPTIONS" screen.

(2) LOCAL NETWORK CHECK

Check the network communication status in the shop.

- 1** In the "NETWORK OPTIONS" screen, select "LOCAL NETWORK CHECK", and press the Enter switch. The "LOCAL NETWORK CHECK" screen appears.
- 2** Press the Enter switch to confirm your selection.



"LOCAL NETWORK CHECK" screen

Item	Description	Display
(a) CHECK START	Check the network communication status in the shop.	—
(b) CABLE	"OK" is displayed if the LAN cable is connected correctly.	OK/NG
(c) TENPO ROUTER	The connection to the shop router is checked. "OK" is displayed if the connection is established, "NG" is displayed if the connection fails.	OK/NG
(d) CONTENTS ROUTER	The item name is displayed in gray. ("OK" or "NG" is not displayed.)	—

- 3** Flip the select switch up and down to select "EXIT" and press the Enter switch to return to the "NETWORK OPTIONS" screen.

1

2

3

4

5

6

7A

7B

8

9

10

Operation


Test Mode

Troubleshooting

(3) ACTIVATION

Check the status of the housing signature information, and perform activation.

- 1** In the "NETWORK OPTIONS" screen, select "ACTIVATION", and press the Enter switch. The "ACTIVATION" screen appears.
- 2** Press the Enter switch to confirm your selection.



"ACTIVATION" screen

Item	Description
(a) BANDAINAMCO PCB ID	Displays the serial number of the dongle.
(b) CURRENT TIME (UTC)	Displays the current time (Universal Standard Time).
(c) GENERATE ONE-TIME KEY	Displays the information for generating a one-time key.
(d) STATUS	Displays the status of the one-time key.
(e) ONE-TIME KEY	Displays the one-time key.
(f) EXPIRY DATE (UTC)	Displays the expiry period (Universal Standard Time) of the one-time key.
(g) EXPIRY DATE (LOCAL)	Displays the expiry period (local time) of the one-time key.
(h) REQUEST SIGNATURE	Displays the items related to acquiring the housing signature information.
(i) STATUS	Displays the status of the acquisition process of the housing signature information.
(j) AUTHENTICATION	Displays the status of the housing signature information.

- 3** Flip the Select switch up and down to select "EXIT" and press the Enter switch to return to the "NETWORK OPTIONS" screen.

● Activation procedure

Use the following procedure on the "ACTIVATION" screen to update the housing signature information.

* Housing signature information

This information is used as part of security improvements for our online-supported products. By performing activation, you can obtain the housing signature information via the Internet.

* Refer to the following procedure only when you are asked to perform activation after contacting us due to an error during operation.

<Preparations>

Prepare the following in order to update the housing signature information.

- Something to take note of the BANDAINAMCO PCB ID and one-time key
 - * These are long strings of numbers, so it is recommended to take a photo of these.
- A computer, smartphone, or other device that can access the Internet via a browser
- Information for logging in to the activation site that was provided in advance
 - * This is issued separately by each shop.

Confirm the following in order to update the housing signature information.

- The game machine is connected to the NBLINE

NOTICE

- While the power switch of the game machine is ON, do not remove or insert the USB dongle.
- Activation is a series of steps that must be performed within 24 hours. If the time in the "EXPIRY DATE" on the "ACTIVATION" screen expires during operation, repeat the procedure again starting from step 1.

- 1** Operate the Select switch to select "GENERATE ONE-TIME KEY", and press the Enter switch to issue the one-time key.
- 2** When the one-time key is issued successfully, "OK" appears in "STATUS". Make note of the BANDAINAMCO PCB ID and one-time key.
- 3** Using a computer or smartphone, access the activation site (<https://am.nbline.net/>), and log in using the provided activation site login information.

NBLINE

👤

🔒

If you forget your password, please contact your sales representative or distributor.

Activation site "Login" screen

1

2

3

4

5

6

7A

7B

8

9

10

Operation

Test Mode

Troubleshooting

- 4 In the Search field of the browser screen, enter the BANDAINAMCO PCB ID recorded in step 2 above ①, and select the BANDAINAMCO PCB ID displayed in the BOARD LIST ②.
- 5 The "BANDAINAMCO PCB ID" selected at the top of the screen is displayed. In the "ONE-TIME KEY" field, enter the one-time key recorded in step 2 above ③.

NBLINE logoff

ONE-TIME KEY ENTRY

BANDAINAMCO PCB ID(12 digits)* 123456789012

ONE-TIME KEY(8 digits)* 01234567

* without hyphens "-"

Clear Confirm

BOARD LIST

Show 10 entries Search: 123456789012

No	BANDAINAMCO PCB ID	LOCATION ID	LOCATION NAME	GAME ID	LAST ACCESS DATE(UTC)
301	123456789012	JPN01234	LOCATION A	A321	2020-02-03 08:28:20

Showing 1 to 1 of 1 entries (filtered from 307 total entries) Previous 1 Next


Activation site "Activate one-time key" screen

- 6 Click "Confirm" ④. The message "YOUR ONE-TIME KEY HAS BEEN ACTIVATED" is displayed.
- 7 Operate the Select switch on the "ACTIVATION" screen of the game machine to select "REQUEST SIGNATURE", and press the Enter switch.
- 8 "OK" is displayed in "STATUS" and "AUTHENTICATION", indicating that the housing signature information has been updated.
 - * If "DONGLE ERROR" is displayed, turn OFF the power switch of the game machine, install the correct dongle, and display the "ACTIVATION" screen again.
 - * If "PLEASE VERIFY ON THE ACTIVATION SITE" is displayed, register the one-time key on the activation site, select "REQUEST SIGNATURE" again, and press the Enter switch.
 - * If "ISSUANCE ERROR" is displayed, repeat step 1 to issue a key, and perform activation using the correct procedure.
 - * If any other errors occur, contact your distributor.

6-6-5 Card Reader/Writer Test (CARD READER-WRITER TEST)

Check whether the card reader/writer operates correctly.

- 1** In the "MENU" screen, select "CARD READER-WRITER TEST", and press the Enter switch. The "CARD READER-WRITER TEST" screen appears.
- 2** Flip the Select switch up or down to select the items. Press the Enter switch to enter the item.
- 3** Flip the select switch up and down to select "EXIT" and press the Enter switch to return to the "MENU" screen.



"CARD READER-WRITER TEST" screen

Item	Description
(a) CARD R/W HARDWARE TEST	Check whether the card reader/writer can correctly communicate with cards. (See P-36 "6-6-5 (1) CARD R/W HARDWARE TEST".)
(b) CARD R/W LAMP TEST	Check whether the LED of the card reader/writer lights up correctly. (See P-38 "6-6-5 (2) CARD R/W LAMP TEST".)
(c) CARD R/W SOUND TEST	Check whether the beep sound is emitted from the built-in speaker of the card reader/writer. (See P-39 "6-6-5 (3) CARD R/W SOUND TEST".)

1

2

3

4

5

6

7A

7B

8

9

10

Operation


Test Mode

Troubleshooting

(1) CARD R/W HARDWARE TEST


Check whether the card reader/writer can communicate with the IC card, etc. correctly.

- 1** In the "CARD READER-WRITER TEST" screen, select "CARD R/W HARDWARE TEST", and press the Enter switch. The "CARD R/W HARDWARE TEST" screen appears.




"CARD R/W HARDWARE TEST" screen

- 2** While "TEST START" is blinking, press the Enter switch to set the card reader/writer to the read standby state (LED blinks blue). The text "PLEASE TOUCH THE CARD R/W WITH YOUR CARD" appears followed by a number that counts down from 10.



"CARD R/W HARDWARE TEST" test progress screen (1)


- 3** While the countdown is proceeding, touch the card reader/writer with the IC card, etc. If the communication is successful, the LED of the card reader/writer indicates that the reading was successful (green light turns on). At the same time, a short beep sound is emitted. Also, "OK" appears on the screen.
- 4** Flip the select switch up and down to select "EXIT" and press the Enter switch to return to the "CARD READER- WRITER TEST" screen.
- If there is a communication error between the game PC board and the card reader/writer, and you did not touch the card reader/writer with the IC card, etc., the following error message is displayed.

**"CARD R/W HARDWARE TEST" test progress screen (2)**

(2) CARD R/W LAMP TEST

Check whether the LED of the card reader/writer lights up correctly.

- 1** In the "CARD READER-WRITER TEST" screen, select "CARD R/W LAMP TEST", and press the Enter switch. "ON" is displayed, and the LED of the card reader/writer blinks repeatedly in the following sequence: red -> green -> blue -> red -> green.




"CARD R/W LAMP TEST" test progress screen

- 2** Press the Enter switch again to quit the test. The display returns to the state where the items in "CARD READER-WRITER TEST" are able to be selected.

(3) CARD R/W SOUND TEST

Check whether the beep sound is emitted from the built-in speaker of the card reader/writer.

- 1** In the "CARD READER-WRITER TEST" screen, select "CARD R/W SOUND TEST", and press the Enter switch to start the test.

**"CARD R/W SOUND TEST" test progress screen**

- 2** "ON" is displayed, and a sound (do re mi fa so la ti do) is emitted for approximately 2-3 seconds from the card reader/writer. When the sound is being emitted, the system does not respond to any input.
- 3** After the sound (lasting for approximately 2-3 seconds) ends, the display returns to the state where the items in "CARD READER-WRITER TEST" are able to be selected.

1

2

3

4

5

6

7A

7B

8

9

10


Operation

Test Mode

Troubleshooting

6-6-6 Switch I/O Test (I/O TEST)

- 1** In the "MENU" screen, select "I/O TEST", and press the Enter switch. The "I/O TEST" screen appears.
- 2** Flip the Select switch up or down to select the items. The selected item blinks red.
- 3** Press the Enter switch. The test screen of the selected item appears.
- 4** Flip the select switch up and down to select "EXIT" and press the Enter switch to return to the "MENU" screen.



"I/O TEST" screen

Item	Description
(a) SWITCH TEST	Perform the switch test. See P-41 "6-6-6(1) Switch Test (SWITCH TEST)".
(b) TAIKO TEST	Adjust the sensor of the taiko drum assembly. See P-42 "6-6-6(2) Adjusting the Taiko Drum Assembly Sensor (TAIKO TEST)".
(c) LAMP TEST	Check the lamp. See P-44 "6-6-6(3) Lamp Test (LAMP TEST)".
(d) CODE READER TEST	Performs a code reader test. See P-45 "6-6-6(4) Code Reader Test (CODE READER TEST)".

Item	Description
(e) I/O PCB	The information of the I/O PC board being connected is displayed. It is normal if "CONNECT OK" is displayed in green text.

(1) Switch Test (SWITCH TEST)

- 1** In the "I/O TEST" screen, select "SWITCH TEST", and press the Enter switch. The "SWITCH TEST" screen appears.
- 2** Operate each switch. The display changes from "OFF" to "ON".
- 3** Flip the Select switch up while pressing the Enter switch. The display returns to the "I/O TEST" screen.

SWITCH TEST	
[ON: RED]	
(a) →	COIN 0
(b) →	SERVICE OFF
(c) →	TEST ON
(d)(e) →	SELECT (UP/DOWN) OFF/OFF
(f) →	ENTER OFF
UP SELECT SW + ENTER SW : EXIT	

"SWITCH TEST" screen

Item	Description
(a) COIN	The value increases by 1 for each coin inserted. When it exceeds 999, the value returns to 0. The coin counter is linked.
(b) SERVICE	When the Service switch is pressed, "ON" is displayed in red text.
(c) TEST	"ON" is displayed in red text. When the Test switch is turned off, the display returns to the game screen.
(d) SELECT UP	When the Select switch is flipped up, "ON" is displayed in red text.
(e) SELECT DOWN	When the Select switch is flipped down, "ON" is displayed in red text.
(f) ENTER	When the Enter switch is pressed, "ON" is displayed in red text.

1

2

3

4

5

6

7A

7B

8

9

10

Operation


Test Mode

Troubleshooting

(2) Adjusting the Taiko Drum Assembly Sensor (TAIKO TEST)

Check the response when the surface and rim of the taiko drum assembly are hit by the drumsticks, and adjust the system's input sensitivity level (the level of intensity required for the system to recognize that the taiko drum assembly has been hit) at each input location.

- 1** In the "I/O TEST" screen, select "TAIKO TEST", and press the Enter switch. The "TAIKO TEST" screen appears.
- 2** Flip the Select switch up or down to select the items. The selected item blinks red.
- 3** Press the Enter switch. The value of the selected item blinks. Flip the Select switch up or down to increase or decrease the value.
- 4** After adjusting the value, press the Enter switch. The display returns to the item selection screen.
- 5** Hit the surface and rim of the taiko drum assembly with appropriate intensity to check that the system responds correctly.



"TAIKO TEST" screen

Item	Description	Setting	Initial setting
(a) Surface	Set the intensity level for both 1P and 2P where the system recognizes that the surface (2 locations on the left and right) of the taiko drum assembly has been hit.	1 to 99	5
(b) Surface (Big)	Set the intensity level for both 1P and 2P where the system recognizes that the surface (2 locations on the left and right) of the taiko drum assembly has been hit hard.	2 to 100	25
(c) Rim	Set the intensity level for both 1P and 2P where the system recognizes that the rim (2 locations on the left and right) of the taiko drum assembly has been hit.	1 to 99	5
(d) Rim (Big)	Set the intensity level for both 1P and 2P where the system recognizes that the rim (2 locations on the left and right) of the taiko drum assembly has been hit hard.	2 to 100	25
(e) Input gauge	When the system recognizes that the surface or rim of the taiko drum assembly has been hit, the gauge brightens up for a while.	–	–
(f) Value of the most recent input	The intensity with which the surface or rim of the taiko drum was hit most recently.	–	0

- 6** After finishing the adjustment, flip the select switch up and down to select "EXIT" and press the Enter switch to return to the "I/O TEST" screen.

1

2

3

4

5

6

7A

7B

8

9

10


Operation

Test Mode

Troubleshooting

(3) Lamp Test (LAMP TEST)

- 1** In the "I/O TEST" screen, select "LAMP TEST", and press the Enter switch. The "LAMP TEST" screen appears.
- 2** Flip the Select switch up or down to select the items. The selected item blinks red.
- 3** Each time the Enter switch is pressed, "ON" and "OFF" are switched between for the selected item. While "ON" is selected, the LED light of the corresponding item lights up.
- 4** Flip the select switch up and down to select "EXIT" and press the Enter switch to return to the "I/O TEST" screen.




"LAMP TEST" screen

Item	Description
(a) WHITE LED	While "ON" is displayed, the LED light (side) (white) lights up.
(b) COLOR LED	While "ON" is displayed for each of the RED, GREEN, and BLUE items, the LED light (side) (full color) lights up in the corresponding color.

(4) Code Reader Test (CODE READER TEST)

- 1** In the "I/O TEST" screen, select "CODE READER TEST", and press the Enter switch. The "CODE READER TEST" screen appears.
- 2** Flip the Select switch up or down to select the items. Press the Enter switch to enter the item.
- 3** Flip the select switch up and down to select "EXIT" and press the Enter switch to return to the "I/O TEST" screen.



"CODE READER TEST" screen

Item	Description
(a) Code display area	Displays the details read with the code reader.
(b) CODE READER LAMP TEST	When "ON" is displayed, the code reader LED lights up.

*If the code reader is disconnected or a code reader error occurs, "8-1 CODE READER ERROR" appears in the middle of the screen.

1

2

3

4

5

6

7A

7B

8

9

10


Operation

Test Mode

Troubleshooting

6-6-7 Monitor Test (MONITOR TEST)

- 1** In the "MENU" screen, select "MONITOR TEST", and press the Enter switch. The "MONITOR TEST" screen appears.
- 2** Flip the Select switch up or down to select the items. The selected item blinks red.
- 3** Press the Enter switch. The pattern screen of the blinking item appears. Press the Enter switch again to return from the pattern screen.
- 4** Flip the select switch up and down to select "EXIT" and press the Enter switch to return to the "MENU" screen.



"MONITOR TEST" screen

Item	Description
(a) GRADATION PATTERN	A 16-level gradation pattern made up of RGB and white is displayed.
(b) CROSSHATCH PATTERN	A crosshatch pattern is displayed.
(c) FULL WHITE	The entire display is displayed in white.
(d) SCROLL PATTERN	Display the moving image and check whether the horizontal scanning process is running correctly.

6-6-8 Sound Test (SOUND TEST)

- 1** In the "MENU" screen, select "SOUND TEST", and press the Enter switch. The "SOUND TEST" screen appears.
- 2** Flip the Select switch up or down to select the items. The selected item blinks red.
- 3** Press the Enter switch. The value of the selected item blinks red. Flip the Select switch up or down to change the setting. The setting is shown in yellow once it is changed (the standard setting is shown in green).
- 4** Press the Enter switch again to select another item.
- 5** Flip the select switch up and down to select "EXIT" and press the Enter switch to return to the "MENU" screen.

SOUND TEST				
[DEFAULT IN GREEN]				
(a)	→	VOLUME	GAME BGM	(0~15) 15
(b)	→		GAME SE	(0~15) 15
(c)	→		ATTRACT BGM	(0~15) 15
(d)	→		ATTRACT SE	(0~15) 15
(e)	→	OUTPUT LEVEL	SPEAKER	80%
(f)	→		WOOFER	100%
(g)	→	REQUEST NO.		1*
(h)	→	LR CHECK		
(i)	→	MESSAGE	LEFT	
EXIT				
Hitting the surface or rim will make a drum sound.				
SELECT SW: CHOOSE ENTER SW: ENTER				
SERVICE SW: REQUEST ON/OFF				

"SOUND TEST" screen

1

2

3

4

5

6

7A

7B

8

9

10

Operation

Test Mode

Troubleshooting

6. Operation

Item	Description	Setting	Initial setting
(a) VOLUME GAME BGM	Adjust the volume of the BGM during the game. Initial value (green)	0 to 15	15
(b) VOLUME GAME SE	Adjust the volume of the SE during the game. Initial value (green)	0 to 15	15
(c) VOLUME ATTRACT BGM	Adjust the volume of the BGM during the Attract mode. Initial value (green)	0 to 15	15
(d) VOLUME ATTRACT SE	Adjust the volume of the SE during the Attract mode. Initial value (green)	0 to 15	15
(e) OUTPUT LEVEL SPEAKER	Set the sound output level of the side speaker and center speaker.	0 to 100%	80%
(f) OUTPUT LEVEL WOOFER	Set the sound output level of the woofer speaker.	0 to 100%	100%
(g) REQUEST NO.	Specify the sound to be played when the Enter switch is pressed while an item is being selected.	0 to 2	0
(h) LR CHECK	The stereo check sound is played when the Enter switch is pressed while an item is being selected.	–	–
(i) MESSAGE	The source of the sound being played is displayed (from either of the side speakers (LEFT or RIGHT), from both channels (LEFT + RIGHT), or from the woofer (WOOFER)). (Sound is always output from the center speaker through both LEFT and RIGHT channels.)	–	–

6-6-9 Displaying and Initializing the Game Data (BOOKKEEPING)

Display various kinds of game data.

- 1** In the "MENU" screen, select "BOOKKEEPING", and press the Enter switch. The "BOOKKEEPING" screen appears.
- 2** The data will not be lost when the game machine power switch is turned off. The data is erased only when "BOOKKEEPING INITIALIZE" in the "BOOKKEEPING" screen or "BACKUP MEMORY INITIALIZE" in the "OTHERS" screen is executed. If "BOOKKEEPING INITIALIZE" is executed, only the "BOOKKEEPING" data is initialized.
- 3** Flip the select switch up and down to select "EXIT" and press the Enter switch to return to the "MENU" screen.

1

2

3

4

5

6

7A

7B

8

9

10

Operation


Test Mode

Troubleshooting

6-6-10 Other Options (OTHERS)

Display various kinds of information and erase various kinds of data. Initialize the settings.

- 1** In the "MENU" screen, select "OTHERS", and press the Enter switch. The "OTHERS" screen appears.
- 2** Select "BACKUP MEMORY INITIALIZE", and press the Enter switch. "NO" and "YES" is displayed. Select "YES", and press the Enter switch. All data stored in the backup memory of the game machine is erased.
- 3** Flip the select switch up and down to select "EXIT" and press the Enter switch to return to the "MENU" screen.




"OTHERS" screen

Item	Description
(a) DATA1	The data name and date are displayed.
(b) CLOCK	The current time obtained on-line is displayed.
(c) S/N	The serial number of the game machine is displayed.
(d) USB S/N	The serial number of the USB dongle is displayed.
(e) ATTRACT MOVIE	Set whether to play a moving image during the Attract mode.
(f) LANGUAGE	Changes part of the language display during the game. Select from "JPN" (Japanese), "ENG" (English), "KOR" (Korean), or "zh-tw" (Traditional Chinese).
(g) BACKUP MEMORY INITIALIZE	Select this item, and press the Enter switch to initialize all data stored in the backup memory.

6-6-11 RELOAD NBLINE POINTS

This screen displays the NBLINE POINTS charged in the machine.

- 1** In the MENU screen, select RELOAD NBLINE POINTS. The following screen appears.
- 2** Flip the Select switch up or down to select CHECK SERVER POINTS and press the Enter button. The charged NBLINE POINTS are displayed.
- 3** Select EXIT and press the Enter button to return to the MENU screen.



RELOAD NBLINE POINTS screen

Item	Description
(a) NBLINE SERVER	Displays the connection status with the NBLINE SERVER.
(b) POINT REMAIN	Displays the charged NBLINE POINTS.
(c) CHECK SERVER POINTS	Select this item to communicate with the server and check the remaining NBLINE POINTS.

1

2

3

4

5

6

7A

7B

8

9

10

Operation

Test Mode

Troubleshooting

6-6-12 Software Update (SOFTWARE UPDATE)

This screen can be used to check the software update status.

* Automatically updates the software using NBLINE such as to add new songs or change the software.

We let you know in advance before performing an update.

- When an update notice is displayed during the operation, always update the software.
- If the software is not the latest version, it may cause problems during game operation.
- If an error occurs during update, turn the power switch off, wait for approximately 30 seconds, then turn it on again to update the software. If the error recurs, contact the distributor.

(1) Checking the Status of Software Updates

- 1** In the "MENU" screen, select "SOFTWARE UPDATE", and press the Enter switch. The "SOFTWARE UPDATE" screen appears.
- 2** The "SOFTWARE UPDATE" screen can be used to check the software version and other information of the game PC board. If no update software is distributed over the network, a message appears indicating that there is no software to be updated.

"SOFTWARE UPDATE" screen

Item	Display	Description
(a) STATUS	OK	Indicates that the latest version of software has been applied.
	DOWNLOADING	Indicates that downloading of the update software is in progress.
	DOWNLOADED	Indicates that downloading of the update software is complete.
	UPDATABLE	Indicates that an update will be started when the machine restarts.

*Even after downloading of the update software is complete, the update will not start until the update implementation date.

Item	Description
(b) DATA INSTALLATION	Use this when updating the software with the USB flash drive.

- 3** In the "SOFTWARE UPDATE" screen, select "DATA INSTALLATION", and press the Enter switch. The "DATA INSTALLATION" screen appears.

"DATA INSTALLATION" screen

Use the DATA INSTALLATION screen to check the USB flash drive for software update connected to the USB 2 port on the game PC board and to install the update.

Item	Description
(c) CHECK DATA	When this is selected and the Enter switch is pressed, "YES/NO" is displayed. Select "YES" and press the Enter switch to check the update data on the USB flash drive.
(d) INSTALL DATA	This can be selected after performing CHECK DATA above. When this is selected and the Enter switch is pressed, "YES/NO" is displayed. Select "YES" and press the Enter switch to install the update from the USB flash drive.
(e) INSTALLED DATA No.	Displays the installed update file numbers.

- 1** Use the Select switch to select "EXIT" and press the Enter switch to return to the "SOFTWARE UPDATE" screen. Once the update has been successfully installed, the game machine will restart automatically.

1

2

3

4

5

6

7A

7B

8

9

10

Operation

Test Mode

Troubleshooting

6-7 Automatic Software Updates

While the software update is being executed, do not turn off the power of the game machine or remove the USB dongle.

If the power cord is pulled out, the power switch is turned off, or the USB dongle is removed while the software update is being executed, the game PC board data may be damaged, which may prevent the game machine from starting up.

- 1** Once downloading of the update software is complete, the update starts automatically after the game machine power switch is turned on or after the test switch is turned off.

*If any unused credit remains, or if it is less than 30 minutes before the time set in P-26, "6-6-3 (1) CLOCK/CLOSE TIME SETTING", the following screen will not appear, and the update will not run.

"SOFTWARE UPDATE" screen

- 2** After the update is complete, perform P-52 "6-6-11 (1) Checking the Status of Software Updates" in the Test mode, to check for any software updates.


6-8 Cleaning

6-8-1 Cleaning the Taiko Drum Assembly

NOTICE

- Do not use paint thinner or other organic solvents. This may degrade the materials.

- 1** Wipe away any dirt using a cloth moistened with a neutral cleanser or water.
- 2** Dry well by wiping cleanser or water away using a dry cloth.



1

2

3

4

5

6

7A

7B

8

9

10

Operation

Test Mode


Troubleshooting

6-8-2 Cleaning the Monitor Glass

NOTICE

- Do not use paint thinner or other organic solvents. This may degrade the materials.

- 1** Wipe the surface of the monitor glass using a cloth moistened with a neutral cleanser or water, while being careful not to scratch the surface.
- 2** Wipe the surface of the monitor glass well again using a dry cloth.



7. Technician's Manuals - Must be performed by a technician -

7A. Installation and Assembly


7A-1 Disassembly

7A-1-1 Removing and Attaching the POP Frame Assembly

⚠ WARNING

- When attaching the POP frame assembly, use a stepladder or stepstool and perform the work with at least two technicians, as you will be working at a height. Having awkward positioning while working may result in an unexpected accident.

- 1** Remove the monitor frame cover (A) placed on the upper side of the monitor frame assembly. (See P-101 "8B-3-2 (3) Removing and Attaching the Monitor Frame Covers (A) and (B)".)
- 2** Remove the two connectors.



1

2

3

4

5

6

7A

7B

8

9

10



Installation and Assembly Manual for Technical Personnel

Test Mode

Troubleshooting

- Must be performed by a technician -

- 3** Remove the torx bolts (M5 x 12), three on each side, pull the two connectors out of the holes, then remove the POP frame assembly.



- Must be performed by a technician -

7A-1-2 Removing and Attaching the Taiko Drum Assembly

⚠ WARNING



- The taiko drum assembly weighs about 30 lb. When removing it, use two or more people and secure an adequate amount of work space to prevent accidents.

1 Remove the four flange sockets (M8 x 20) and a connector, then remove the taiko drum assembly.

2 To attach it, perform the procedure in reverse.

NOTICE

- After attaching the taiko drum assembly, be sure to check and adjust the sensor performance. (See P-42 "7-6-6 (2) Adjusting the Taiko Drum Assembly Sensor (TAIKO TEST)".)



1

2

3

4

5

6

7A

7B

8


9

10


- Must be performed by a technician -

7A-1-3 Removing and Attaching the Card Box (QR-EXP) Assembly

- 1** Remove the card reader CV4 (EXP).
(See P-110 "8B-3-4 (1) Replacing the Card Reader/Writer".)
- 2** Remove the four button head screws (M5 x 20) and four flat washers (M5).



- 3** Remove the four connectors, one USB terminal, and one cord clip, then remove the card box (QR-EXP) assembly.



- 4** To attach it, perform the procedure in reverse.

- Must be performed by a technician -



7A-2 Assembly

7A-2-1 Adjusting the Level Adjusters

⚠ WARNING

- Be sure to install the game machine securely by using the level adjusters. Failure to do so may result in an unexpected accident.

- 1 After installing the product according to P-12 [5-1 Installation Conditions], lower the four level adjusters of the cabinet base assembly so that the game machine will be positioned stably and stay level, then adjust the position of the casters so that they will be lifted 5 mm off the floor.



1

2

3

4

5

6

7A

7B

8

9

10

Test Mode

Troubleshooting


- Must be performed by a technician -

7A-2-2 Assembling the POP Frame Assembly


⚠ WARNING

- When attaching the light box, use a stepladder or stepstool and perform the work with at least two technicians, as you will be working at a height. Having an awkward posture while working may result in an unexpected accident.

- 1** Loosen the upper torx bolt (M5 x 12, one of each), remove the lower torx bolt (M5 x 12, one of each), then remove the light box.



- 2** Remove the torx bolts (M5 x 12, two of each), then remove the shipping brackets, (L) and (R).




- Must be performed by a technician -

- 3** Remove the torx bolt (M5 x 12, one of each) on the (L) and (R) shipping brackets, and attach them temporarily to the back of the Light box.

- 4** Attach the character POP bracket in place on the Light box using the torx bolts (M5 x 12, two on each side) you have removed in step 2.

Remove the torx bolts (M5 x 12) loosened in step 1.

**NOTICE**

- Store the (L) and (R) shipping brackets that you have just removed in safe keeping as they are needed for transfer or transport.

- 5** Insert the POP frame (R) into the hole on the Light box and the torx bolt (M5 x 12) temporarily attached in step 3, attach it using the torx bolt (M5 x 12) removed in step 1 and supplied torx bolt (M5 x 12), then engage the connector.

1

2

3

4

5

6

7A

7B

8

9

10

Test Mode

Troubleshooting

- Must be performed by a technician -




- 6** Attach the POP harness cover in place on the POP frame (R), using the supplied torx bolt (M5 x 12, black).

NOTICE

- When attaching, ensure that the connector(s) is (are) locked securely.
- When attaching it, exercise care to ensure the harness does not get tucked in.

- 7** Attach the POP frame (L) in the same manner.

- 8** Attach the POP frame assembly.



- Must be performed by a technician -


7A-2-3 Attaching the POP Assembly

! WARNING


- When attaching the light box, prepare a stepstool or similar object as you will be working at a height. Having awkward positioning while working may cause an injury or damage the game machine. Be sure to utilize two or more people for this operation.

(1) Attaching the 2024 Ver. Middle POP

- Attach the 2024 Ver. middle POP to the middle POP bracket using six each torx bolts (M5 x 12, silver) and flat washers (M5, silver), with the printed surface of the middle POP facing forward.



- Bend the middle POP reinforcement along the folds in the order of [1] and [2] shown below, and then remove the release paper of the double-sided tape, and attach the middle POP reinforcement to the guide on the rear of the 2024 Ver. middle POP while aligning the corners.



1

2

3

4

5

6

7A

7B


8

9

10


- Must be performed by a technician -

- 3** Loosen the two torx bolts (M5 x 12) at the top of the POP frame assembly, attach the Middle POP bracket, and then fully tighten the two loosened torx bolts (M5 x 12).



- Must be performed by a technician -**(2) Attaching the 2024 Ver. Character POP**

- 4** Remove the protective sheet attached to the front surface of the 2024 Ver. character POP.
- 5** Attach the 2024 Ver. character POP to the character POP bracket with the four torx bolts (M5 x 12, black).



1

2

3

4

5

6

7A

7B

8


9

10

- Must be performed by a technician -

(3) Attaching the 2024 Ver. Back POP


- 6** Slide the 2024 Ver. back POP between the POP frame and monitor frame, and secure using three each torx bolts (M5 x 12, silver) and flat washers (M5, silver).
- 7** Loosen the three torx bolts (M5x12) and remove the back pop retainer from the middle pop bracket. After that, loosen the Torx bolt so that there is a gap of about 3 mm from the dollar pop bracket.
- 8** Insert the 2024 Ver. back POP so that its notches fit under the three torx bolts (M5 x 12) temporarily fastened in 2.
- 9** Insert the back POP retainer under the 2024 Ver. back POP according to the three torx bolts (M5x12) of 2 and fix it.



- Must be performed by a technician -

(4) Attaching the 2024 Ver. Side POP (L) and (R)

- 1** Attach the 2024 Ver. side POP (R) using three each torx bolts (M5 x 12, silver) and flat washers (M5, silver).
- 2** Attach the 2024 Ver. side POP (L) in the same way.



1

2

3

4

5

6

7A

7B

8

9

10


Test Mode

Troubleshooting

- Must be performed by a technician -

(5) Inserting the Introduction Sheet (HOW TO PLAY) A4 Set

- 3** Insert the Introduction Sheet (HOW TO PLAY) A4 Set into the pockets of the 2024 Ver. side POP (L) and (R) while matching the numbers below.



- Must be performed by a technician -

7A-3 Connecting the Power Cord and Ground Wire


⚠ WARNING

- To prevent yourself and/or other people from receiving an electric shock, having an accident or being injured, and to prevent electronic circuits from being damaged, be sure to turn off the main power switch before starting operations.
- When connecting the supplied power cord with a three-pronged plug, connect to a two-pole grounded outlet (15A/125V or 20A/125V), and ensure that grounding is performed. Insufficient grounding may result in short circuiting or electric shock. The use of an outlet that prevents accidental disconnection is recommended.
- Fully insert the power cord plug into the outlet. Poor contact may generate heat and result in a fire or burns.


⚠ CAUTION

- Lay out the power cords safely so that they will not cause players, bystanders or passersby to trip over them.

- 1** Insert the power cord socket into the power socket of the cord box assembly positioned at the rear bottom side of the cabinet base assembly.
- 2** Fix the power cord in place using the TL clamp.



- 3** Insert the power code plug of the power cord into the power outlet.
Insert the power code plug as-is.



1

2

3

4

5

6

7A

7B

8

9

10

- Must be performed by a technician -

7A-4 Inserting the USB Dongle


⚠ WARNING

- To prevent yourself and/or other people from receiving an electric shock, having an accident or being injured, and to prevent electronic circuits from being damaged, be sure to turn off the main power switch before starting operations.

NOTICE


- The USB dongle is exclusively for use with this game machine. Do not use it for other instruments. In addition, do not insert a USB dongle not designed for this game machine. Doing so may result in mechanical malfunction.
- Be sure to turn off the power switch before inserting the USB dongle.
- Be sure to attach the same combination of the USB dongle, one each, for each game PC board.

- 1 Unlock the key for coin lock, then remove the left maintenance door.



- Must be performed by a technician -

- 2** Insert the USB dongle in "USB1" on the game PC board.



- 3** To attach the maintenance door, perform the procedure in step **1** in reverse.

1

2

3

4

5

6

7A

7B

8

9

10

- Must be performed by a technician -

7A-5 Connecting the LAN Cable

WARNING

- To prevent yourself and/or other people from receiving an electric shock, having an accident or being injured, and to prevent electronic circuits from being damaged, be sure to turn off the main power switch before starting operations.

CAUTION


- Lay out the LAN cables safely so that they will not cause players, bystanders or passersby to trip over them.

NOTICE

- In order to prevent damage to the electrical circuitry, be sure to turn the power switch off before connecting the LAN cable. (See P-76 7A-6 Turning On the Power Switch .)
- When laying the LAN cable on the floor, we recommend the use of a commercial cable mold to protect the cables.
- Failure to follow the instructions below may result in communication errors and hinder normal game playing. Strictly follow these instructions for connecting the LAN cable.
 - Communications may fail if the LAN cable is coming out of the connector. Lay out the LAN cables safely so that they will not cause players, bystanders or passersby to trip over them.
 - Do not bundle the LAN cable and the power cord together, and do not wire them together in the same mold.
 - Do not forcibly bend the LAN cable or subject it to strain. Install it so that no extra load is applied to it.

- Must be performed by a technician -

- 1** Unlock the coin lock and remove the maintenance door.
- 2** (See P-84 "8B-3-1 (1) Removing and Attaching the Maintenance Door".)
- 3** Pass the supplied LAN cable through the side of the rack assembly in the bottom of the cabinet base assembly to the backside of the cabinet.
- 4** Fix the LAN cable passing through the inside of the cabinet base assembly then connect it to the game PC board.
- 5** Connect the LAN cable connected to the game PC board to the shop router that is connected to NBLINE.



Connect the LAN cable to the shop router (connected to NBLINE).

1

2

3

4

5

6

7A

7B

8


9

10

- Must be performed by a technician -

7A-6 Turning On the Power Switch

- 1 Turn on the power switch located at the rear bottom side of the cabinet base assembly.



NOTICE

- Do not turn the power switch on or off unless it is necessary. Not observing this can cause machine failure.
- When turning the power switch on or off, wait a minimum of 30 seconds after the preceding on or off operation.

7A-7 Post-Installation Check

After all installation procedures have been completed, inspections required for starting daily business operations must be performed.

(See P-15 6-3 Pre-Operation Inspection

Check the following items before opening the game arcade. If any abnormalities are detected, take necessary measures by referencing P- 7B-2 Troubleshooting . .)

As required, set up the game cost and/or sound levels.

(See P-21 6-5-2 Adjustment Switches and P-22 6-6 Test Mode .)

7B. Service

1
2
3
4
5
6
7A
7B
8
9
10

⚠ WARNING

● Before starting servicing (troubleshooting, repair, replacement, etc.), be sure to turn off the power switch to prevent yourself and/or other people from receiving an electric shock, having an accident or being injured, and to prevent electronic circuits from being damaged.

7-1 Inspection and Service - Must be performed by a technician -

⚠ WARNING

Perform periodic servicing. Omitting this service may result in an unexpected accident. Perform the inspections on a daily basis before starting business operations. These are required to prevent accidents.
(See P-15 □6-3 Pre-Operation Inspection Check the following items before opening the game arcade. If any abnormalities are detected, take necessary measures by referencing P- □7B-2 Troubleshooting □. □.)

7B-1-1 What to Inspect

Check the following inspection items periodically for abnormalities.

(1) Level Adjuster

- Ensure that the game machine is positioned stably.
(See P-61 □7A-2-1 Adjusting the Level Adjusters □.)

(2) Power Cord Plug

- Check that the power cord is firmly inserted into the power outlet in the game machine's cord box. (See P-83 □7B-1-1 Network System Troubleshooting □.)
- Clean any dust or other dirt from the connection parts.
- Check for cracks or dirt on the power cord covering. If the power cord shows any signs of abnormalities, be sure to replace it.

(3) Loose Screws (All Components)

- Screws fixing the taiko drum assembly
(See P-59 □7A-1-2 Removing and Attaching the Taiko Drum Assembly □.)
- Separately set (according to the delivery conditions) fixing screws
(See P-57 □7A-1-1 Removing and Attaching the POP Frame Assembly □.)

- Must be performed by a technician -

7B-2 Troubleshooting

⚠ WARNING

- To prevent yourself and/or other people from receiving an electric shock, having an accident or being injured, and to prevent electronic circuits from being damaged, be sure to turn off the main power switch before starting operations.
- If the given problem does not fall under any of the items described in "8B-2 Troubleshooting" or when your measures do not improve the situation, turn the power switch off promptly, disconnect the power cord plug from the outlet to stop operation and contact your distributor. Continuing the operation as is can lead to an unexpected accident.

NOTICE

- If a problem is detected, check first of all whether the connectors are securely connected.
- If the given problem does not fall under the items from P-78 to P-82, or when your measures do not improve the situation, contact your distributor.
- PC board repairs are to be conducted by our company. Never perform a conductivity check of the boards with a tester or any other tool.
Otherwise the IC may be damaged by the internal voltage of the tester.
- When sending parts for repair, be sure to package them securely. In particular, when sending the PC board, enclose it in foam packaging or bubble wrap and place it in a cardboard box so as not to apply external force.

7B-2-1 General

Symptom	Major cause	Action	Reference page
<ul style="list-style-type: none"> • Operation is not stable or the game machine does not operate correctly. 	<ul style="list-style-type: none"> • The power supply voltage is outside the range of 220 VAC $\pm 10\%$. 	<ul style="list-style-type: none"> • Disconnect any high-capacity devices (such as an air conditioner or large machine) from the same line to secure the specified power supply voltage. 	---
<ul style="list-style-type: none"> • The power turns off during operation. 	<ul style="list-style-type: none"> • The circuit protector has activated to turn the power switch off. * The circuit protector turns off the current when an abnormal current occurs. 	<ul style="list-style-type: none"> • Turn on the power switch again. If the circuit protector operates frequently, a mechanical abnormality may be occurring. Contact your distributor. 	P-20
<ul style="list-style-type: none"> • Game software does not operate normally. 	<ul style="list-style-type: none"> • A game PC board is malfunctioning. 	<ul style="list-style-type: none"> • Turn the power switch off once, then turn it on again after approximately 30 seconds. 	P-20

- Must be performed by a technician -

7B-2-2 Cabinet Base Assembly

Symptom	Major cause	Action	Reference page
• No sound is output from the woofer speaker.	• The volume setting is low.	• Adjust the sound volume.	P-47
	• The Faston terminal of the woofer speaker is disconnected.	• Connect the Faston terminal of the woofer speaker.	---
	• The connector is disconnected or not inserted far enough.	• Insert the connector the appropriate distance.	P-83 P-88 P-90
	• AMP PC board has failed.	• Replace the AMP PC board.	P-90

7B-2-3 Monitor Frame Assembly

Symptom	Major cause	Action	Reference page
• No sound is output from the speaker.	• The volume setting is low.	• Adjust the sound volume.	P-47
	• The Faston terminal of the speaker is disconnected.	• Connect the Faston terminal of the speaker.	---
	• The connector is disconnected or not inserted far enough.	• Insert the connector the appropriate distance.	P-83 P-88 P-90
	• AMP PC board has failed.	• Replace the AMP PC board.	P-90
• The LED light does not light up.	• The LED light has gone out.	• Replace the LED light.	P-97 P-99
	• The connector is disconnected.	• Connect the connector securely.	P-97 P-99
	• The USIO (T) PC board has failed.	• Replace the USIO (T) PC board.	P-92
• The monitor does not display images.	• The connector for the monitor is disconnected.	• Connect the connector.	P-83 P-102
	• The monitor has failed.	• Replace the monitor.	P-102

7B-2-4 Taiko Drum Assembly

Symptom	Major cause	Action	Reference page
• The reaction of the surface or rim is not normal. The portion that has been hit does not respond. Or sections that have not been hit also respond.	• Setting of the intensity level at which the system recognizes the taiko drum has been hit is not appropriate.	• Re-set the intensity level.	P-42
	• The connector is disconnected.	• Insert the connector securely.	P-59 P-107
	• The sensor fixing screw is loose.	• Apply thread locking agent to the sensor fixing screw and tighten it. * Do not use the taiko drum until the thread locking agent has hardened.	P-107
	• The sensor has failed.	• Replace the sensor.	P-107
	• SIF 2 PC board has failed.	• Replace SIF 2 PC board.	P-91
	• The taiko drum assembly is damaged.	• Replace the taiko drum assembly.	P-59

1

2

3

4

5

6

7A

7B

8

9

10

Manual for Maintenance Technicians

Test Mode

Troubleshooting

- Must be performed by a technician -

7B-2-5 Card Box (QR-EXP) Assembly

Symptom	Major cause	Action	Reference page
• No sound is output from the speaker.	• The volume setting is low.	• Adjust the sound volume.	P-47
	• The Faston terminal of the speaker is disconnected.	• Connect the Faston terminal of the speaker.	---
	• The connector is disconnected or not inserted far enough.	• Insert the connector the appropriate distance.	P-60 P-83 P-88 P-90
	• AMP PC board has failed.	• Replace the AMP PC board.	P-90
• The card reader/writer does not respond.	• The card used is not compatible with Bandai Namco Passport.	• Use an IC card that is compatible with Bandai Namco Passport.	P-16
	• The connector is disconnected.	• Connect the connector securely.	P-88 P-110
	• The card reader/writer has failed.	• Replace the card reader/writer.	P-110
	• The USIO (T) PC board has failed.	• Replace the USIO (T) PC board.	P-92

7B-2-6 POP Frame Assembly

Symptom	Major cause	Action	Reference page
• The LED lamp does not light up.	• The LED lamp is loose.	• Tighten the LED lamp securely.	P-114
	• An unspecified lamp is used.	• Use the specified lamp.	P-114
	• The LED lamp has gone out.	• Replace the LED lamp.	P-114
	• The connector is disconnected.	• Connect the connector securely.	P-114
• The LED light does not light up.	• The LED light has gone out.	• Replace the LED light.	P-115
	• The connector is disconnected.	• Connect the connector securely.	P-115
	• The USIO (T) PC board has failed.	• Replace the USIO (T) PC board.	P-92

- Must be performed by a technician -

7B-2-7 Error Messages

Error Message	Major cause	Action	Reference page
WARNING:INCORRECT FIRMWARE VERSION!	<ul style="list-style-type: none"> The USIO (T) PC board version is not the correct one. 	<ul style="list-style-type: none"> Replace the USIO (T) PC board. 	P-92
1-1 Coin error 1	<ul style="list-style-type: none"> The coin selector has failed. 	<ul style="list-style-type: none"> Contact your distributor. 	---
1-2 Coin error 2	<ul style="list-style-type: none"> The service switch has failed. 	<ul style="list-style-type: none"> Contact your distributor. 	---
1-3 Coin error 3	<ul style="list-style-type: none"> The coin counter has failed. 	<ul style="list-style-type: none"> Contact your distributor. 	---
2-3 Backup memory error 1	<ul style="list-style-type: none"> The USIO (T) PC board has failed. 	<ul style="list-style-type: none"> Replace the USIO (T) PC board. 	P-92
2-4 Backup memory error 2			
2-5 Battery error	<ul style="list-style-type: none"> The built-in battery of the USIO (T) PC board has run out. 	<ul style="list-style-type: none"> Replace the USIO (T) PC board. 	P-92
2-8 Battery error 2	<ul style="list-style-type: none"> The game PC board has failed. 	<ul style="list-style-type: none"> Contact your distributor. 	---
3-1 I/O error 1	<ul style="list-style-type: none"> The USIO (T) PC board has failed. The USIO (T) PC board connector is disconnected. 	<ul style="list-style-type: none"> Replace the USIO (T) PC board. Insert the connector securely. 	P-92
3-2 I/O error 2			P-92
3-3 I/O error 3			P-92
5-36 UPDATE SERVER AUTH SIGNATURE	<ul style="list-style-type: none"> The housing signature information is invalid or does not exist. 	<ul style="list-style-type: none"> Contact your distributor. 	---
5-37 UPDATE SERVER AUTH TOKEN	<ul style="list-style-type: none"> Communication of housing signature information failed. 		---
5-50 Software can be updated.	<ul style="list-style-type: none"> The game is provided without a software update. 	<ul style="list-style-type: none"> Update the software. 	P-54
7-1 Card reader not connected	<ul style="list-style-type: none"> The connector is disconnected. 	<ul style="list-style-type: none"> Insert the connector securely. 	P-88 P-110
	<ul style="list-style-type: none"> The card reader/writer has failed. 	<ul style="list-style-type: none"> Replace the card reader/writer. 	P-110
8-1 Code reader connection error	<ul style="list-style-type: none"> Code reader is not connected. 	<ul style="list-style-type: none"> Check that the code reader is connected properly. 	P-120
	<ul style="list-style-type: none"> Code reader has failed. 	<ul style="list-style-type: none"> Contact your distributor. 	---
19-1 System error	<ul style="list-style-type: none"> The USB dongle has failed. The game PC board has failed. 	<ul style="list-style-type: none"> Contact your distributor. 	---
19-2 System error			
20-1 Version update error	<ul style="list-style-type: none"> Failed to update the software. 	<ul style="list-style-type: none"> Contact your distributor. 	---

1

2

3

4

5

6

7A

7B

8

9

10

- Must be performed by a technician -


7B-2-7 Error Messages (Continued)

Error Message	Major cause	Action	Reference page
21-1 Network connection error 1	<ul style="list-style-type: none"> The game machine was operated for a long period of time without being connected to the network (NBLINE). * The game machine has been designed to operate in standalone mode even if the network connection fails for a short period of time. However, if the game machine is disconnected from the network (NBLINE) for a long period of time, its operation may fail. 	<ul style="list-style-type: none"> Connect the game machine to the network (NBLINE). 	P-28
		<ul style="list-style-type: none"> Connect the LAN cable. 	P-74
		<ul style="list-style-type: none"> Replace the LAN cable. 	P-74
22-1 USB dongle error 1	<ul style="list-style-type: none"> A USB dongle of another game machine or an invalid USB dongle has been inserted. 	<ul style="list-style-type: none"> Insert the USB dongle exclusively provided for this game machine. 	P-72
22-2 USB dongle error 2	<ul style="list-style-type: none"> A USB dongle is not inserted. 	<ul style="list-style-type: none"> Insert the USB dongle exclusively provided for this game machine. 	P-72
22-3 USB dongle error 3	<ul style="list-style-type: none"> The USB dongle is damaged. 	<ul style="list-style-type: none"> Contact your distributor. 	---
	<ul style="list-style-type: none"> The game PC board has failed. 		
23-1 SYSTEM ERROR	<ul style="list-style-type: none"> The application is operating outside the proper operating frequency range. 	<ul style="list-style-type: none"> Contact your distributor. 	---
24-1 Network authentication error	<ul style="list-style-type: none"> The network authentication has failed during startup. 	<ul style="list-style-type: none"> Contact your distributor. 	---
25-1 Setup error 1	<ul style="list-style-type: none"> The game machine has failed to obtain the required startup data from the network. 	<ul style="list-style-type: none"> Check the connection state to the game server. Contact your distributor. 	P-28
25-2 Setup error 2			

- Must be performed by a technician -


7B-1-1 Network System Troubleshooting

If a problem occurs in network communication, the Network icon shown below appears on the game screen. Check the following items to identify the communication problem. (When communication is normal, a red slash will not appear over the Network icon.)



If network communication fails, see P-31“ 6-6-4 (2) LOCAL NETWORK CHECK” and P-29“6-6-4 (1) NETWORK STATUS”, and check the network connection. If a problem is found, follow the troubleshooting flowchart.

Network Communication Troubleshooting Flowchart



- 1
- 2
- 3
- 4
- 5
- 6
- 7A
- 7B**
- 8
- 9
- 10

- Must be performed by a technician -

7B-3 Removing, Attaching, and Replacing the Assembly and Parts

7B-3-1 Cabinet Base Assembly

(1) Removing and Attaching the Maintenance Door

WARNING


- To prevent yourself and/or other people from receiving an electric shock, having an accident or being injured, and to prevent electronic circuits from being damaged, be sure to turn off the main power switch before starting operations.

CAUTION

- Some parts of the PC board inside the main unit remain hot even after the power switch is turned off. Be careful not to touch the PC board as doing so may cause a burn injury.

- 1** Turn off the power switch located at the rear bottom side of the cabinet base assembly.
- 2** Remove the Phillips truss screw (M4 x 10), unlock the key for coin lock, then remove the maintenance door.
- 3** To attach it, perform the procedure in reverse.

- Must be performed by a technician -



- 1
- 2
- 3
- 4
- 5
- 6
- 7A
- 7B**
- 8
- 9
- 10

Manual for Maintenance Technicians

Test Mode

Troubleshooting

- Must be performed by a technician -

(2) Replacing the Game PC Board

⚠ WARNING

- To prevent yourself and/or other people from receiving an electric shock, having an accident or being injured, and to prevent electronic circuits from being damaged, be sure to turn off the main power switch before starting operations.

⚠ CAUTION


- Some parts of the PC board inside the main unit remain hot even after the power switch is turned off. Be careful not to touch the PC board as doing so may cause a burn injury

NOTICE

- The PC board is sensitive to static electricity. If a worker whose body contains static electricity handles the PC board, parts of the PC board may be damaged.


Before handling the PC board, remove static electricity by touching the surface of grounded metal, etc.

- 1** Turn off the power switch located at the rear bottom side of the cabinet base assembly.
- 2** Remove the maintenance door.
(See P-84 "8B-3-1 (1) Removing and Attaching the Maintenance Door".)
- 3** Remove the power cable, RS232C cable, audio cable, HDMI cable, LAN cable, USB cables (2), USB dongle, wing bolts (M4 x 15) (2), and PC board base.




- Must be performed by a technician -

4 Remove the two front and rear nuts (M6) and the game PC board.



5 Remove the three Phillips pan head screws (with flat and spring washers) (M4 x 6), then remove the two rack joints.



6 To attach it, perform the procedure in reverse.

NOTICE

- When attaching, ensure that the connector(s) is (are) locked securely.
- Make sure that the power switch of the game PC board is turned on.

1

2

3

4

5

6

7A

7B

8

9

10

- Must be performed by a technician -

(3) Removing and Attaching the Regulator Base

WARNING

- To prevent yourself and/or other people from receiving an electric shock, having an accident or being injured, and to prevent electronic circuits from being damaged, be sure to turn off the main power switch before starting operations.

CAUTION

- Some parts of the PC board inside the main unit remain hot even after the power switch is turned off. Be careful not to touch the PC board as doing so may cause a burn injury.


NOTICE

- The PC board is sensitive to static electricity. If a worker whose body contains static electricity handles the PC board, parts of the PC board may be damaged.


Before handling the PC board, remove static electricity by touching the surface of grounded metal, etc.

- 1** Turn off the power switch located at the rear bottom side of the cabinet base assembly.
- 2** Remove the maintenance door.
(See P-84 "8B-3-1 (1) Removing and Attaching the Maintenance Door".)
- 3** Remove the LAN cable.
(See P-74 [7A-5 Connecting the LAN Cable] .)
- 4** Remove the game PC board.
(See P-86 "8B-3-1 (2) Replacing the Game PC Board".)
- 5** Remove the 12 connectors, then remove the pin plug (white) and the pin plug (red).

- Must be performed by a technician -



- 6** Remove the two Phillips pan head screws (with flat and spring washers) (M4 x 10), then remove the regulator base.



- 7** To attach it, perform the procedure in reverse.

1
2
3
4
5
6
7A
7B
8
9
10

- Must be performed by a technician -

(4) Replacing the AMP PC Board

⚠ WARNING

- To prevent yourself and/or other people from receiving an electric shock, having an accident or being injured, and to prevent electronic circuits from being damaged, be sure to turn off the main power switch before starting operations.


⚠ CAUTION

- Some parts of the PC board inside the main unit remain hot even after the power switch is turned off. Be careful not to touch the PC board as doing so may cause a burn injury.

NOTICE

- The PC board is sensitive to static electricity. If a worker whose body contains static electricity handles the PC board, parts of the PC board may be damaged. Before handling the PC board, remove static electricity by touching the surface of grounded metal, etc.

- 1** Turn off the power switch located at the rear bottom side of the cabinet base assembly.
- 2** Remove the maintenance door, then remove the regulator base.
(See P-88 "8B-3-1 (3) Removing and Attaching the Regulator Base".)
- 3** Remove the five cap screws (M) (M3 x 6) and the connector, and replace the AMP PC board.



- 4** To attach it, perform the procedure in reverse.

NOTICE

- When attaching, ensure that the connector(s) is (are) locked securely.

- Must be performed by a technician -**(5) Replacing the SIF 2 PC Board****! WARNING**

- To prevent yourself and/or other people from receiving an electric shock, having an accident or being injured, and to prevent electronic circuits from being damaged, be sure to turn off the main power switch before starting operations.

! CAUTION


- Some parts of the PC board inside the main unit remain hot even after the power switch is turned off. Be careful not to touch the PC board as doing so may cause a burn injury.

NOTICE

- The PC board is sensitive to static electricity. If a worker whose body contains static electricity handles the PC board, parts of the PC board may be damaged.

Before handling the PC board, remove static electricity by touching the surface of grounded metal, etc.

- 1** Turn off the power switch located at the rear bottom side of the cabinet base assembly.
- 2** Remove the maintenance door, then remove the regulator base.
(See P-88 "8B-3-1 (3) Removing and Attaching the Regulator Base".)
- 3** Remove the four cap screws (M) (M3 x 6) and the connector, and replace the SIF 2 PC board.



- 4** To attach it, perform the procedure in reverse.

NOTICE

- When attaching, ensure that the connector(s) is (are) locked securely.
- After replacing the SIF 2 PC board, be sure to check and adjust the operation of the taiko drum assembly in the test mode. (See P-42 "7-6-6 (2) Adjusting the Taiko Drum Assembly Sensor".)

1

2

3

4

5

6

7A

7B

8

9

10

- Must be performed by a technician -

(6) Replacing the USIO (T) PC Board

⚠ WARNING

- To prevent yourself and/or other people from receiving an electric shock, having an accident or being injured, and to prevent electronic circuits from being damaged, be sure to turn off the main power switch before starting operations.

⚠ CAUTION


- Some parts of the PC board inside the main unit remain hot even after the power switch is turned off. Be careful not to touch the PC board as doing so may cause a burn injury.

NOTICE

The PC board is sensitive to static electricity. If a worker whose body contains static electricity handles the PC board, parts of the PC board may be damaged.

Before handling the PC board, remove static electricity by touching the surface of grounded metal, etc.

- 1** Turn off the power switch located at the rear bottom side of the cabinet base assembly.
- 2** Remove the maintenance door, then remove the regulator base.
(See P-88 "8B-3-1 (3) Removing and Attaching the Regulator Base".)
- 3** Remove the five cap screws (M) (M3 x 6) and the connector, and replace the USIO (T) PC board.



- 4** To attach it, perform the procedure in reverse.

NOTICE

- When attaching, ensure that the connector(s) is (are) locked securely.

- Must be performed by a technician -

(7) Replacing the Switching Regulator


! WARNING

- To prevent yourself and/or other people from receiving an electric shock, having an accident or being injured, and to prevent electronic circuits from being damaged, be sure to turn off the main power switch before starting operations.

! CAUTION

- Some parts of the PC board inside the main unit remain hot even after the power switch is turned off. Be careful not to touch the PC board as doing so may cause a burn injury.

- 1** Turn off the power switch located at the rear bottom side of the cabinet base assembly.
- 2** Remove the maintenance door, then remove the regulator base.
(See P-88 "8B-3-1 (3) Removing and Attaching the Regulator Base".)
- 3** Remove the four cap screws (M) (M3 x 6) on each side, the 5 V and 24 V connectors, and the two 12 V connectors, and replace the 5 V, 12 V, or 24 V switching regulators.



1

2

3

4

5

6

7A

7B

8

9

10

- Must be performed by a technician -

- 4** To attach it, perform the procedure in reverse.

NOTICE


- When attaching, ensure that the connector(s) is (are) locked securely.

(8) Replacing the Drumsticks

- 1** Cut the strap using a pair of scissors or similar tool and remove the old drumsticks.
- 2** Insert the strap of new drumsticks into the hook, pass the drumsticks (left: red, right: blue) through the hoop of the strap, and secure it.

NOTICE

- When you attach the drumsticks, ensure that the strap of the right-hand stick and that of the left-hand stick are equal in length.
- The red drumsticks should be attached on the left-hand side and the blue drumsticks on the right-hand side.




- 3** Secure the knot using a nylon strap.

! CAUTION

Cut off any excess length of nylon strap using a pair of scissors or similar tool. In doing so, ensure that the cut surface is not sharp.

- Must be performed by a technician -



1

2

3

4

5

6

7A

7B

8


9

10

- Must be performed by a technician -

(9) Replacing the Drumstick Bags

- 1** Remove the two button head screws (M4 x 16), remove the drumstick hook, then replace the drumstick bag.



- 2** Attach the other drumstick bag in the same way.

- Must be performed by a technician -


7B-3-2 Monitor Frame Assembly

(1) Replacing the LED Lights (Upper Lights)


⚠ WARNING

- To prevent yourself and/or other people from receiving an electric shock, having an accident or being injured, and to prevent electronic circuits from being damaged, be sure to turn off the main power switch before starting operations.

- 1** Turn off the power switch located at the rear bottom side of the cabinet base assembly.
- 2** Remove the two torx bolts (M5 x 12), then remove the upper light cover.



- 3** Remove the two cap screws (M) (M4 x 10) and raise the upper light reflector toward you.



1

2

3

4

5

6

7A

7B

8

9

10


Manual for Maintenance Technicians

Test Mode

Troubleshooting

- Must be performed by a technician -

- 4** Remove the connector, then remove the upper light reflector.




- 5** Remove the five clamps and replace the LED light with a new one (white).

- 6** To attach it, perform the procedure in reverse.

NOTICE

- When attaching it, secure the LED light (white) so that the clamp will be in the center between the LED elements.




- Must be performed by a technician -

(2) Replacing the LED Lights (side)


⚠ WARNING

- To prevent yourself and/or other people from receiving an electric shock, having an accident or being injured, and to prevent electronic circuits from being damaged, be sure to turn off the main power switch before starting operations.

- 1** Turn off the power switch located at the rear bottom side of the cabinet base assembly.
- 2** Remove the three torx bolts (M5 x 12, silver) and three flat washers (M5, silver), then remove the 2023 Ver. side POP (R).
- 3** Loosen the two torx bolts (M5 x 20), remove the two torx bolts (M5 x 12), then remove the side LED cover (R) and the side cover holder A.



- 4** Remove the six cap screws (M) (M4 x 10), then remove the LED reflector.



1

2

3

4

5

6

7A

7B

8



9

10

- Must be performed by a technician -

5 Remove the five clamps and the connector of the LED light to be replaced, then replace the LED light.

6 Replace the LED light on the left-hand side in the same manner.



7 To attach it, perform the procedure in reverse.

NOTICE

- One LED light is white and the other is full color. Be sure to attach them in the correct positions.
- When attaching it, secure the LED light (white) so that the clamp will be in the center between the LED elements.
- When attaching, ensure that the connector(s) is (are) locked securely.


- Must be performed by a technician -

(3) Removing and Attaching the Monitor Frame Covers (A) and (B)

⚠ WARNING

- To prevent yourself and/or other people from receiving an electric shock, having an accident or being injured, and to prevent electronic circuits from being damaged, be sure to turn off the main power switch before starting operations.

- 1** Turn off the power switch located at the rear bottom side of the cabinet base assembly.
- 2** Use the cabinet entry keys to open the rear cover
- 3** To attach it, perform the procedure in reverse.



1

2

3

4

5

6

7A

7B

8

9

10

- Must be performed by a technician -

(4) Replacing the LCD Monitor


⚠ WARNING

- To prevent yourself and/or other people from receiving an electric shock, having an accident or being injured, and to prevent electronic circuits from being damaged, be sure to turn off the main power switch before starting operations.

- 1** Turn off the power switch located at the rear bottom side of the cabinet base assembly.
- 2** Remove the monitor frame cover (A).
(See P-101 "8B-3-2 (3) Removing and Attaching the Monitor Frame Covers (A) and (B)".)
- 3** Remove the four hexagon head bolts (with flat and spring washers) (M6 x 12), the connector and the HDMI cable. Hold the monitor holder to remove the LCD monitor.

NOTICE

To remove the LCD monitor, lay a soft cloth on the flat surface in advance to prevent the LCD panel from being damaged




- Must be performed by a technician -

4 Remove the six Phillips hexagon head bolt (with flat and spring washers) (M5 x 12), remove the monitor holder, then replace the LCD monitor.

5 To attach it, perform the procedure in reverse.

NOTICE

When attaching the monitor holder, pull the LCD monitor upward so that it does not tilt, and then attach it. When attaching, ensure that the connector(s) is (are) locked securely.



1

2

3

4

5

6

7A

7B

8

9

10

- Must be performed by a technician -

(5) Replacing the Monitor Glass


⚠ WARNING

- To avoid accidents, ensure that you have two or more workers and an adequate amount of space for them to work in.

NOTICE

To remove the monitor glass, remove the glass holder while holding the monitor glass, then remove the monitor glass by pulling it up.

- 1** Loosen the two torx bolts (M5 x 12) on the outside, remove the two torx bolts (M5 x 12) on the inside, remove the glass holder, then replace the monitor glass.
- 2** To attach it, perform the procedure in reverse.



- Must be performed by a technician -


7B-3-3 Taiko Drum Assembly

(1) Replacing the Pad Mask

⚠ WARNING

- To prevent yourself and/or other people from receiving an electric shock, having an accident or being injured, and to prevent electronic circuits from being damaged, be sure to turn off the main power switch before starting operations.

- 1** Turn off the power switch located at the rear bottom side of the cabinet base assembly.
- 2** Remove the hexagon socket head cap screw (M4 x 4) and the hexagon cap nut (M4) on each side and unlock the hook.
- 3** Remove the rim ring.



1

2

3

4

5

6

7A

7B


8

9

10

- Must be performed by a technician -

- 4** Replace the pad masks.
- 5** To attach it, perform the procedure in reverse.



NOTICE

- When attaching it, apply the thread locking agent to the hexagon cap nut (M4) to prevent the screws from coming off due to vibration. Do not use the taiko drum until the thread locking agent has hardened.


- Must be performed by a technician -

(2) Replacing the Sensor


⚠ WARNING

- To prevent yourself and/or other people from receiving an electric shock, having an accident or being injured, and to prevent electronic circuits from being damaged, be sure to turn off the main power switch before starting operations.

- 1** Turn off the power switch located at the rear bottom side of the cabinet base assembly.
- 2** Remove the pad mask.
(See P-105 "8B-3-3 (1) Replacing the Pad Mask".)
- 3** Remove the four Phillips hexagon head bolts (with large diameter flat and spring washers) (M6 x 20).



- 4** Remove the four connectors and remove the sensor together with the base.



1

2

3

4

5

6

7A

7B

8


9

10


- Must be performed by a technician -

[For Pad]

- 1 Remove the three flange nuts (M6) on each pad and remove the pads.



- 2 Remove the two Phillips pan head screws (with flat and spring washers) (M4 x 12), then remove the sensor holder.
- 3 Remove the two wood screws ($\phi 2.3 \times 10$) and replace the sensor.
- 4 To attach it, perform the procedure in reverse. When attaching it, match the colors of the connectors and those of the seals.




NOTICE

- When attaching it, apply the thread locking agent to prevent the screws from coming off due to vibration. Do not use the taiko drum until the thread locking agent has hardened.
- When attaching, ensure that the connector(s) is (are) locked securely.
- When attaching it, align the base and the taiko drum.
- When attaching it, exercise care to ensure the harness and connector do not get tucked in.
- When you attach the wood screw ($\phi 2.3 \times 10$), apply wood adhesive agent to the screw.
- After replacing the sensor, be sure to check and adjust the operation of the sensor in the test mode. (See P-42 "7-6-6 (2) Adjusting the Taiko Drum Assembly Sensor".)


- Must be performed by a technician -

[For Rim]

- 1** Remove the four flange nuts (M6) on each rim and remove the rims.



- 2** Remove the two Phillips pan head screws (with flat and spring washers) (M4 x 12), then remove the sensor holder.
- 3** Remove the two wood screws ($\Phi 2.3 \times 10$) and replace the sensor.
- 4** To attach it, perform the procedure in reverse. When attaching it, match the colors of the connectors and those of the seals.



NOTICE

- When attaching it, apply the thread locking agent to prevent the screws from coming off due to vibration. Do not use the taiko drum until the thread locking agent has hardened.
- When attaching, ensure that the connector(s) is (are) locked securely.
- When attaching it, align the base and the taiko drum.
- When attaching it, exercise care to ensure the harness and connector do not get tucked in.
- When you attach the wood screw ($\Phi 2.3 \times 10$), apply wood adhesive agent to the screw.
- After replacing the sensor, be sure to check and adjust the operation of the sensor in the test mode. (See P-42 "7-6-6 (2) Adjusting the Taiko Drum Assembly Sensor".)

1

2

3

4

5

6

7A

7B

8

9

10

- Must be performed by a technician -


7B-3-4 Card Box (QR-EXP) Assembly

(1) Replacing the Card Reader/Writer


⚠ WARNING

- To prevent yourself and/or other people from receiving an electric shock, having an accident or being injured, and to prevent electronic circuits from being damaged, be sure to turn off the main power switch before starting operations.


- 1** Turn off the power switch located at the rear bottom side of the cabinet base assembly.
- 2** Remove the six torx bolts (M5 x 12), and then remove the card reader CV4 (EXP).



- 3** Remove the four Phillips pan head screws (with flat and spring washers) (M4 x 8) and the connector, then remove the card reader bracket.

- Must be performed by a technician -

- 4** Remove the four Phillips pan head screws (with flat and spring washers) (M4 x 8) and replace the card reader/writer.



- 5** To attach it, perform the procedure in reverse.

NOTICE

- When attaching, ensure that the connector(s) is (are) locked securely.
- After replacing the card reader/writer, be sure to check and adjust the operation of the card reader/writer in the test mode. (See P-35 6-6-5 Card Reader/Writer Test (CARD READER-WRITER TEST) .)

(2) Replacing the LED tape

1

2

3

4

5

6

7A

7B

8

9

10

- Must be performed by a technician -


⚠ WARNING

- To prevent yourself and/or other people from receiving an electric shock, having an accident or being injured, and to prevent electronic circuits from being damaged, be sure to turn off the main power switch before starting operations.

⚠ CAUTION


- The taiko drum assembly weighs about 14 kg. When removing it, use two or more people and secure an adequate amount of work space to prevent accidents.

- 1** Remove the taiko drum assembly (L).
(See P-59 [7A-1-2 Removing and Attaching the Taiko Drum Assembly] .)
- 2** Remove the card box (QR-EXP) assembly.
(See P-60 [7A-1-3 Removing and Attaching the Card Box (QR-EXP) Assembly] .)
- 3** Remove the three torx bolts (M5 x 6), one connector and five fixing tabs from each side, remove the LED covers (L) and (R) and LED shade (S), and replace the LED tape (250 mm).



- Must be performed by a technician -

- 4** Remove the two torx bolts (M5 x 6), one connector and three fixing tabs, remove the LED lid (R) and LED shade (R), and replace the LED tape (100 mm).



- 5** To attach it, perform the procedure in reverse.

NOTICE

- When attaching it, secure the LED tape so that the fixing tabs are at the middle position between the LED elements.
- When attaching, ensure that the connector(s) is (are) locked secure

(3) Replacing the Code Reader**⚠ WARNING**

- To prevent yourself and/or other people from receiving an electric shock, having an accident or being injured, and to prevent electronic circuits from being damaged, be sure to turn off the main power switch before starting operations.

- 1** Remove the six torx bolts (M5 x 12), and then remove the card reader CV4 (EXP).
(See P-110 "8B-3-4 (1) Replacing the Card Reader/Writer".)
- 2** Remove the two low head cap screws (M5 x 12), and then remove the QR code reader CV (EXP).
- 3** Remove the four Phillips pan head screws (M3 x 6) and one connector, and then remove the code reader.
- 4** To attach it, perform the procedure in reverse.

NOTICE

- When attaching, connect the connector before attaching the code reader.
- When attaching it, ensure that the connectors are pressed in securely.

1

2

3

4

5

6

7A

7B

8

9

10

- Must be performed by a technician -

7B-3-5 POP Frame Assembly

(1) Replacing the LED Lamps


⚠ WARNING

- To prevent yourself and/or other people from receiving an electric shock, having an accident or being injured, and to prevent electronic circuits from being damaged, be sure to turn off the main power switch before starting operations.
- When attaching the POP frame assembly, prepare a stepstool or similar object as you will be working at a height. Having an awkward posture while working may cause an injury or damage the game machine. Be sure to utilize two or more people for this operation.

⚠ CAUTION

- Some parts of the LED lamp remain hot even after the power switch is turned off, and can cause a burn injury. Before working on it, ensure that it has cooled down.

- 1** Turn off the power switch located at the rear bottom side of the cabinet base assembly.
- 2** Remove the four torx bolts (M5 x 12, black), then remove the 2023 Ver. character POP.
- 3** Remove the torx bolt (M5 x 12), then remove the POP harness cover and connector.
- 4** Loosen the torx bolt (M5 x 12) and remove the two torx bolts (M5 x 12) on either side, and remove the Light box from the POP frame (L) and (R).
- 5** Remove the six button head screws (M4 x 12), then remove the POP light cover.
- 6** Remove the LED lamp by rotating it counterclockwise, and replace it with a new one.



NOTICE

- Ensure that the LED lamp has the specified rating. Do not use an LED lamp that has a higher rating or a lamp other than an LED (a filament lamp, etc.). Otherwise the POP light cover may be damaged by heat or the circuit protector may malfunction.

- Must be performed by a technician -

(2) Replacing the LED Lights (POP light)


⚠ WARNING

To prevent yourself and/or other people from receiving an electric shock, having an accident or being injured, and to prevent electronic circuits from being damaged, be sure to turn off the main power switch before starting operations.

⚠ CAUTION

- Some parts of the LED lamp remain hot even after the power switch is turned off, and can cause a burn injury. Before working on it, ensure that it has cooled down.

- 1** Remove the Light box. (See P-114 "8B-3-5 (1) Replacing the LED Lamp".)
- 2** Remove the Character POP bracket. (See P-62 "8A-2-2 Assembling the POP Frame Assembly step 4")
- 3** Remove the eight torx bolts (M5 x 12), then remove the POP light cover.
 - *There are projections to hook the POP light cover on the rear side of the light box base. To remove the POP light cover, pull up the rear side of the cover.



- 4** Remove the connector and the five clamps on each side, and replace the LED light with a new one (white).
- 5** To attach it, perform the procedure in reverse.

NOTICE

- When attaching it, secure the LED light (white) so that the clamp will be in the center between the LED elements.
- When attaching, ensure that the connector(s) is (are) locked securely.

1

2

3

4

5

6

7A



7B

8

9

10

- Must be performed by a technician -



8. Disposal

WARNING

When disposing of the game machine, follow the applicable regulations for collection, transportation and disposal.

When delegating the collection, transportation and disposal of the game machine, be sure to delegate such work to specialists in each field.

NOTICE

- The software included in this game machine is protected by copyright laws. It is prohibited to copy, adapt, distribute publicly, or use this software for purposes other than the operation of this game machine. Violations of copyright laws may result in criminal penalties.
Do not use the recording media containing the software for other models. Doing so may result in mechanical malfunction.

1

2

3

4

5

6

7A

7B

8

9

10


Disposal

Test Mode

Troubleshooting

9. Parts List

9-1 Cabinet Assembly (1)



No.	Name	Quantity	[Model and Rating]	Part Number
1	Cabinet Assembly	1		****
2	Wi-Fi cover	1		TNT10-24137-00
3	Glass holder	1		TNT10-24146-00
4	Side cover holder (A)	2		TNT10-24146-00
5	Drumstick hook	2		TNT10-24111-00
6	LED reflector (L)	2		TNT10-24116-00
7	LED reflector (R)	2		TNT10-24116-01
8	Upper light reflector	1		TNT10-24117-00
9	Monitor holder	1		TNT10-24142-00
10	Drumstick bag	2		TNT97-24219-00
11	Side speaker box	2		TNT10-24115-00
12	Side speaker cover (L)	1		TNT90-24221-00
13	Side speaker cover (R)	1		TNT90-24221-01
14	Side LED cover (L)	1		TNT90-24222-00
15	Side LED cover (R)	1		TNT90-24222-01
16	BN passport card reader ASSY	1		TNT03-24103-00
17	Title panel 3 (EXP)	1		TNT40-24155-00
18	Monitor sticker (A)	1		TNT40-24156-00
19	Decal, Cabinet Base Coin Door	1		TNT40-24154-00
20	Drum	2		TNT90-24211-00
21	HDMI Cable	1	HDMI 2.0	TNT50-24182-00
22	LED tape light white	3		TNT79-24161-00
23	LED tape light full color	2		TNT79-24162-00
24	Side speaker	2	F00213D0	TNT10-24115-00
25	Monitor front sticker 2	1		TNT40-24158-00
26	Drumsticks S (Left: Red)	1		TNT63-24217-00
27	Drumsticks S (Right: Blue)	1		TNT63-24217-00
28	Side cover holder (B)	2		TNT10-24138-00
29	Camera cover	1		TNT40-24156-00
30	Side cushion	2		TNT96-24179-00
31	Decal, Cabinet Base Left	1		TNT40-24152-00
32	Decal, Cabinet Base Right	1		TNT40-24153-00
33	32-inch LCD monitor	1		TNT85-24165-00

1

2

3

4

5

6

7A

7B

8

9


10

Parts List

Test Mode


Troubleshooting

9-2 Card Box (QR-EXP) Assembly



No.	Name	Quantity	[Model and Rating]	Part Number
1	Card box CV2	1		TNT10-24121-00
2	LED cover (L)	1		TNT10-24122-00
3	LED cover (R)	1		TNT10-24122-01
4	LED lid (R)	1		TNT10-24123-00
5	LED shade (S)	2		****
6	LED shade (R)	1		****
7	QR code reader CV (EXP)	1		****
8	Code Reader	1		TNT15-24151-00
9	LED tape (250 mm)	2	L=250 mm	TNT79-24163-00
10	LED tape (100 mm)	1	L=100 mm	TNT79-24163-00
11	Center box speaker	1		****
12	Card reader bracket	1		TNT79-24163-00
13	Card reader CV4 (EXP)	1		****
14	Speaker	1	F00213D0	TNT54-24173-00
15	Bandai Namco Passport card reader (ID) assembly	1	Cover with sticker	TNT03-24103-00

9-3 POP Frame Assembly



No.	Name	Quantity	[Model and Rating]	Part Number
1	POP frame (L)	1		TNT10-24124-00
2	POP frame (R)	1		TNT10-24124-01
3	POP light box base 2	1		TNT10-24125-00
4	POP light cover	2		TNT90-24214-00
5	POP light cover (C)	1		TNT90-24215-00
6	Middle POP bracket	1		TNT10-24127-00
7	Back POP retainer	1		TNT10-24128-00
8	Light bracket 2	2		TNT10-24126-00
9	LED bracket	2		TNT10-24129-00
10	Reflector	1		TNT57-24216-00
11	POP harness cover	2		TNT10-24130-00
12	Character POP bracket	2		TNT10-24131-00
13	LED emergency sticker (7W)	2		****
14	LED tape light white	2		TNT79-24161-00
15	LED lamp	2		TNT57-24174-00
16	Lamp socket	2	WW3402	TNT57-24175-00

1

2

3

4

5

6

7A

7B

8

9


10

Parts List

Test Mode


Troubleshooting

9-4 POP Assembly



No.	Name	Quantity	[Model and Rating]	Part Number
1	2024 Ver. back POP	1		TNT40-24239-00
2	2024 Ver. middle POP	1		TNT40-24240-00
3	2024 Ver. character POP	1		TNT40-24241-00
4	2024 Ver. side POP (L)	1		TNT40-24242-00
5	2024 Ver. side POP (R)	1		TNT40-24242-01
6	Middle POP reinforcement	2		TNT40-24243-00
7	Introduction Sheet (HOW TO PLAY) A4 Set 2024 Ver. (set of 4 sheets)	1		TNT40-24245-00

9-5 Cord Box Assembly



No.	Name	Quantity	[Model and Rating]	Part Number
1	Cord box	1		TNT10-24112-00
2	Circuit protector	1		TNT52-24168-00
3	Noise filter	1		TNT48-24169-00


- 1
- 2
- 3
- 4
- 5
- 6
- 7A
- 7B
- 8
- 9
- 10

Parts List

Test Mode


Troubleshooting

9-6 Regulator Assembly



No.	Name	Quantity	[Model and Rating]	Part Number
1	Regulator base	1		TNT10-24113-00
2	Switching regulator (5 V)	1		TNT88-24170-00
3	Switching regulator (12 V)	2		TNT88-24171-00
4	Switching regulator (24 V)	1		TNT88-24172-00

9-7 Other Items



No.	Name	Quantity	[Model and Rating]	Part Number
1	User's Manual, 1st edition (this publication)	1		TNT45-24177-00
2	LAN cable	1		VG50-19399-00
3	USB Cable			TNT50-24183-00
4	Audio Cable			TNT50-24181-00

- 1
- 2
- 3
- 4
- 5
- 6
- 7A
- 7B
- 8
- 9
- 10


Parts List

Test Mode


Troubleshooting

10. Wiring Diagram


(1/3)



1
2
3
4
5
6
7A
7B
8
9
10
Wiring Diagram
Test Mode
Troubleshooting



- 1
 - 2
 - 3
 - 4
 - 5
 - 6
 - 7A
 - 7B
 - 8
 - 9
 - 10
- Wiring Diagram
- Test Mode
- Troubleshooting



- 1
- 2
- 3
- 4
- 5
- 6
- 7A
- 7B
- 8
- 9
- 10

Wiring Diagram

Test Mode

Troubleshooting

The copyrighted music included with this game machine is licensed for use in the domestic Japanese market by the Japanese Society for Rights of Authors, Composers and Publishers (JASRAC) and by Japan Rights Clearance, Inc.

The software indicated below is licensed for use on this game machine by third party organizations.

Refer to the licensing conditions shown below.

Camellia

Copyright 2006, 2007

NTT (Nippon Telegraph and Telephone Corporation). All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer as the first lines of this file unmodified.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY NTT "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED.

IN NO EVENT SHALL NTT BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Protocol Buffers

Protocol Buffers - Google's data interchange format

Copyright 2008 Google Inc. All rights reserved.

<http://code.google.com/p/protobuf/>

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of Google Inc. nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED.

IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

MPEG-4 AVC License

THIS PRODUCT IS LICENSED UNDER THE AVC PATENT PORTFOLIO LICENSE FOR THE PERSONAL AND NON-COMMERCIAL USE OF A CONSUMER TO

(i) ENCODE VIDEO IN COMPLIANCE WITH THE AVC STANDARD ("AVC VIDEO") AND/OR

(ii) DECODE AVC VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL AND NON-COMMERCIAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED TO PROVIDE AVC VIDEO.

NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE.

ADDITIONAL INFORMATION MAY BE OBTAINED FROM MPEG LA, LLC.

SEE [HTTP://WWW.MPEGLA.COM](http://www.mpegla.com)

Refer to the following URL for other licenses and trademarks used by this machine.

<http://www.bandainamcogames.co.jp/aa/am/vg/s357-license/>

Other system and product names are generally the registered trademarks or trademarks of each company.

Must comply with each country's regulations when used in other countries. This does not comply with RoHS directive in the EU, and import may be punishable. In order to use this machine in the foreign country, it must suit the regulation of each country.

Moreover, because it doesn't suit the RoHS Directive of Europe, the importer might be punished.

This product uses the following third party software with approval.
Please see below for licensing conditions:

cereal

Copyright (c) 2014, Randolph Voorhies, Shane Grant
All rights reserved.

Redistribution and use in source and binary forms, with or without
modification, are permitted provided that the following conditions
are met:

- * Redistributions of source code must retain the above copyright
notice, this list of conditions and the following disclaimer.
- * Redistributions in binary form must reproduce the above
copyright notice, this list of conditions and the following
disclaimer in the documentation and/or other materials
provided with the distribution.
- * Neither the name of cereal nor the names of its contributors
may be used to endorse or promote products derived from this
software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS
AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED
WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED
WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A
PARTICULAR PURPOSE ARE
DISCLAIMED. IN NO EVENT SHALL RANDOLPH VOORHIES OR
SHANE GRANT BE LIABLE FOR ANY
DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR
CONSEQUENTIAL DAMAGES
(INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF
SUBSTITUTE GOODS OR SERVICES;
LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION)
HOWEVER CAUSED AND
ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT,
STRICT LIABILITY, OR TORT
(INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY
OUT OF THE USE OF THIS
SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH
DAMAGE.

RapidJSON

Tencent is pleased to support the open source community by
making RapidJSON available.

Copyright (C) 2015 THL A29 Limited, a Tencent company, and Milo Yip. All rights reserved.

If you have downloaded a copy of the RapidJSON binary from Tencent, please note that the RapidJSON binary is licensed under the MIT License.

If you have downloaded a copy of the RapidJSON source code from Tencent, please note that RapidJSON source code is licensed under the MIT License, except for the third-party components listed below which are subject to different license terms. Your integration of RapidJSON into your own projects may require compliance with the MIT License, as well as the other licenses applicable to the third-party components included within RapidJSON. To avoid the problematic JSON license in your own projects, it's sufficient to exclude the bin/jsonchecker/ directory, as it's the only code under the JSON license.

A copy of the MIT License is included in this file.

Other dependencies and licenses:

Open Source Software Licensed Under the BSD License:

The msinttypes r29
Copyright (c) 2006-2013 Alexander Chemeris
All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- * Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- * Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- * Neither the name of copyright holder nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE REGENTS AND CONTRIBUTORS ``AS IS'' AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE REGENTS AND CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES

(INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Open Source Software Licensed Under the JSON License:

json.org
Copyright (c) 2002 JSON.org
All Rights Reserved.

JSON_checker
Copyright (c) 2002 JSON.org
All Rights Reserved.

Terms of the JSON License:

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

The Software shall be used for Good, not Evil.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Terms of the MIT License:

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation

files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software. THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

flatbuffers

Copyright 2014 Google Inc. All rights reserved.

Apache License
Version 2.0, January 2004
<http://www.apache.org/licenses/>

TERMS AND CONDITIONS FOR USE, REPRODUCTION, AND DISTRIBUTION

1. Definitions.

"License" shall mean the terms and conditions for use, reproduction, and distribution as defined by Sections 1 through 9 of this document.

"Licensor" shall mean the copyright owner or entity authorized by the copyright owner that is granting the License.

"Legal Entity" shall mean the union of the acting entity and all other entities that control, are controlled by, or are under common control with that entity. For the purposes of this definition, "control" means (i) the power, direct or indirect, to cause the direction or management of such entity, whether by contract or otherwise, or (ii) ownership of fifty percent (50%) or more of the outstanding shares, or (iii) beneficial ownership of such entity.

"You" (or "Your") shall mean an individual or Legal Entity exercising permissions granted by this License.

"Source" form shall mean the preferred form for making modifications, including but not limited to software source code, documentation source, and configuration files.

"Object" form shall mean any form resulting from mechanical transformation or translation of a Source form, including but not limited to compiled object code, generated documentation, and conversions to other media types.

"Work" shall mean the work of authorship, whether in Source or Object form, made available under the License, as indicated by a copyright notice that is included in or attached to the work (an example is provided in the Appendix below).

"Derivative Works" shall mean any work, whether in Source or Object form, that is based on (or derived from) the Work and for which the editorial revisions, annotations, elaborations, or other modifications represent, as a whole, an original work of authorship. For the purposes of this License, Derivative Works shall not include works that remain separable from, or merely link (or bind by name) to the interfaces of, the Work and Derivative Works thereof.

"Contribution" shall mean any work of authorship, including the original version of the Work and any modifications or additions to that Work or Derivative Works thereof, that is intentionally submitted to Licensor for inclusion in the Work by the copyright owner or by an individual or Legal Entity authorized to submit on behalf of the copyright owner. For the purposes of this definition, "submitted" means any form of electronic, verbal, or written communication sent to the Licensor or its representatives, including but not limited to communication on electronic mailing lists, source code control systems, and issue tracking systems that are managed by, or on behalf of, the Licensor for the purpose of discussing and improving the Work, but excluding communication that is conspicuously marked or otherwise designated in writing by the copyright owner as "Not a Contribution."

"Contributor" shall mean Licensor and any individual or Legal Entity on behalf of whom a Contribution has been received by Licensor and subsequently incorporated within the Work.

2. Grant of Copyright License. Subject to the terms and conditions of this License, each Contributor hereby grants to You a perpetual, worldwide, non-exclusive, no-charge, royalty-free, irrevocable copyright license to reproduce, prepare Derivative Works of, publicly display, publicly perform, sublicense, and distribute the Work and such Derivative Works in Source or Object form.

3. Grant of Patent License. Subject to the terms and conditions of this License, each Contributor hereby grants to You a perpetual, worldwide, non-exclusive, no-charge, royalty-free, irrevocable (except as stated in this section) patent license to make, have made, use, offer to sell, sell, import, and otherwise transfer the Work, where such license applies only to those patent claims licensable by such Contributor that are necessarily infringed by their Contribution(s) alone or by combination of their Contribution(s) with the Work to which such Contribution(s) was submitted. If You institute patent litigation against any entity (including a cross-claim or counterclaim in a lawsuit) alleging that the Work or a Contribution incorporated within the Work constitutes direct or contributory patent infringement, then any patent licenses granted to You under this License for that Work shall terminate as of the date such litigation is filed.

4. Redistribution. You may reproduce and distribute copies of the Work or Derivative Works thereof in any medium, with or without modifications, and in Source or Object form, provided that You meet the following conditions:
 - (a) You must give any other recipients of the Work or Derivative Works a copy of this License; and
 - (b) You must cause any modified files to carry prominent notices stating that You changed the files; and
 - (c) You must retain, in the Source form of any Derivative Works that You distribute, all copyright, patent, trademark, and attribution notices from the Source form of the Work, excluding those notices that do not pertain to any part of the Derivative Works; and
 - (d) If the Work includes a "NOTICE" text file as part of its distribution, then any Derivative Works that You distribute must include a readable copy of the attribution notices contained within such NOTICE file, excluding those notices that do not pertain to any part of the Derivative Works, in at least one of the following places: within a NOTICE text file distributed as part of the Derivative Works; within the Source form or documentation, if provided along with the Derivative Works; or, within a display generated by the Derivative Works, if and wherever such third-party notices normally appear. The contents of the NOTICE file are for informational purposes only and do not modify the License. You may add Your own attribution notices within Derivative Works that You distribute, alongside or as an addendum to the NOTICE text from the Work, provided that

such additional attribution notices cannot be construed as modifying the License.

You may add Your own copyright statement to Your modifications and may provide additional or different license terms and conditions for use, reproduction, or distribution of Your modifications, or for any such Derivative Works as a whole, provided Your use, reproduction, and distribution of the Work otherwise complies with the conditions stated in this License.

5. Submission of Contributions. Unless You explicitly state otherwise, any Contribution intentionally submitted for inclusion in the Work by You to the Licensor shall be under the terms and conditions of this License, without any additional terms or conditions. Notwithstanding the above, nothing herein shall supersede or modify the terms of any separate license agreement you may have executed with Licensor regarding such Contributions.
6. Trademarks. This License does not grant permission to use the trade names, trademarks, service marks, or product names of the Licensor, except as required for reasonable and customary use in describing the origin of the Work and reproducing the content of the NOTICE file.
7. Disclaimer of Warranty. Unless required by applicable law or agreed to in writing, Licensor provides the Work (and each Contributor provides its Contributions) on an "AS IS" BASIS, WITHOUT WARRANTIES OR CONDITIONS OF ANY KIND, either express or implied, including, without limitation, any warranties or conditions of TITLE, NON-INFRINGEMENT, MERCHANTABILITY, or FITNESS FOR A PARTICULAR PURPOSE. You are solely responsible for determining the appropriateness of using or redistributing the Work and assume any risks associated with Your exercise of permissions under this License.
8. Limitation of Liability. In no event and under no legal theory, whether in tort (including negligence), contract, or otherwise, unless required by applicable law (such as deliberate and grossly negligent acts) or agreed to in writing, shall any Contributor be liable to You for damages, including any direct, indirect, special, incidental, or consequential damages of any character arising as a result of this License or out of the use or inability to use the Work (including but not limited to damages for loss of goodwill, work stoppage, computer failure or malfunction, or any and all other commercial damages or losses), even if such Contributor has been advised of the possibility of such damages.

9. Accepting Warranty or Additional Liability. While redistributing the Work or Derivative Works thereof, You may choose to offer, and charge a fee for, acceptance of support, warranty, indemnity, or other liability obligations and/or rights consistent with this License. However, in accepting such obligations, You may act only on Your own behalf and on Your sole responsibility, not on behalf of any other Contributor, and only if You agree to indemnify, defend, and hold each Contributor harmless for any liability incurred by, or claims asserted against, such Contributor by reason of your accepting any such warranty or additional liability.

END OF TERMS AND CONDITIONS

jemalloc

Unless otherwise specified, files in the jemalloc source distribution are subject to the following license:

Copyright (C) 2002-2016 Jason Evans <jasone@canonical.com>. All rights reserved.
Copyright (C) 2007-2012 Mozilla Foundation. All rights reserved.
Copyright (C) 2009-2016 Facebook, Inc. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice(s), this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice(s), this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDER(S) "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER(S) BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

picojson

* Copyright 2009-2010 Cybozu Labs, Inc.

* Copyright 2011-2014 Kazuho Oku

* All rights reserved.

*

* Redistribution and use in source and binary forms, with or without

* modification, are permitted provided that the following conditions are met:

*

* 1. Redistributions of source code must retain the above copyright notice,

* this list of conditions and the following disclaimer.

*

* 2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

* THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS"

* AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE

* IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE

* ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTRIBUTORS BE

* LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR

* CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF

* SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS

* INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN

* CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE)

* ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE

* POSSIBILITY OF SUCH DAMAGE.

Protocol Buffers

// Protocol Buffers - Google's data interchange format

// Copyright 2008 Google Inc. All rights reserved.

// <https://developers.google.com/protocol-buffers/>

//

// Redistribution and use in source and binary forms, with or

without
// modification, are permitted provided that the following conditions
are
// met:
//
// * Redistributions of source code must retain the above
copyright
// notice, this list of conditions and the following disclaimer.
// * Redistributions in binary form must reproduce the above
// copyright notice, this list of conditions and the following
disclaimer
// in the documentation and/or other materials provided with the
// distribution.
// * Neither the name of Google Inc. nor the names of its
// contributors may be used to endorse or promote products
derived from
// this software without specific prior written permission.
//
// THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS
AND CONTRIBUTORS
// "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES,
INCLUDING, BUT NOT
// LIMITED TO, THE IMPLIED WARRANTIES OF
MERCHANTABILITY AND FITNESS FOR
// A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT
SHALL THE COPYRIGHT
// OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT,
INDIRECT, INCIDENTAL,
// SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES
(INCLUDING, BUT NOT
// LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR
SERVICES; LOSS OF USE,
// DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER
CAUSED AND ON ANY
// THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT
LIABILITY, OR TORT
// (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY
WAY OUT OF THE USE
// OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY
OF SUCH DAMAGE.

expat
Copyright (c) 1998-2000 Thai Open Source Software Center Ltd
and Clark Cooper
Copyright (c) 2001-2017 Expat maintainers

half
half - IEEE 754-based half-precision floating point library.
Copyright (c) 2012-2017 Christian Rau <rau@users.sourceforge.

net>

Lua

Copyright (C) 1994-2008 Lua.org, PUC-Rio. All rights reserved.

LuaJIT

LuaJIT -- a Just-In-Time Compiler for Lua. <http://luajit.org/>

Copyright (C) 2005-2017 Mike Pall. All rights reserved.

sol2

Copyright (c) 2013-2018 Rapptz, ThePhD and contributors

spdlog

Copyright (c) 2016 Gabi Melman.

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

This product is covered by patent rights licensed from Telefonaktiebolaget LM Ericsson

MICROSOFT SOFTWARE LICENSE TERMS

WINDOWS 10 IOT ENTERPRISE & MOBILE (ALL EDITIONS)

IF YOU LIVE IN (OR IF YOUR PRINCIPAL PLACE OF BUSINESS IS IN) THE UNITED STATES, PLEASE READ THE BINDING ARBITRATION CLAUSE AND CLASS ACTION WAIVER IN SECTION 9. IT AFFECTS HOW DISPUTES ARE RESOLVED.

Thank you for choosing Microsoft!

Depending on how you obtained the Windows software, this is a license agreement between (i) you and the device manufacturer or software installer that distributes the software with your device; or (ii) you and Microsoft Corporation (or, based on where you live or if a business where your principal place of business is located, one of its affiliates) if you acquired the software from a retailer. Microsoft is the device manufacturer for devices produced by Microsoft or one of its affiliates, and Microsoft is the retailer if you acquired the software directly from Microsoft.

This agreement describes your rights and the conditions upon which you may use the Windows software. You should review the entire agreement, including any supplemental license terms that accompany the software and any linked terms, because all of the terms are important and together create this agreement that applies to you. You can review linked terms by pasting the (aka.ms/) link into a browser window.

By accepting this agreement or using the software, you agree to all of these terms, and consent to the transmission of certain information during activation and during your use of the software as per the privacy statement described in Section 3. If you do not accept and comply with these terms, you may not use the software or its features. You may contact the device manufacturer or installer, or your retailer if you purchased the software directly, to determine its return policy and return the software or device for a refund or credit under that policy. You must comply with that policy, which might require you to return the software with the entire device on which the software is installed for a refund or credit, if any.

1. Overview.

- a. **Applicability.** This agreement applies to the Windows software that is preinstalled on your device, or acquired from a retailer and installed by you, the media on which you received the software (if any), any fonts, icons, images or sound files included with the software, and also any Microsoft updates, upgrades, supplements or services for the software, unless other terms come with them. It also applies to Windows apps developed by Microsoft that provide functionality such as mail, calendar, contacts, music and news that are included with and are a part of Windows. If this agreement contains terms regarding a feature or service not available on your device, then those terms do not apply.
- b. **Additional terms.** Depending on your device's capabilities, how it is configured, and how you use it, additional Microsoft and third party terms may apply to your use of certain features, services and apps.
 - (i) Some Windows apps provide an access point to, or rely on, online services, and the use of those services is sometimes governed by separate terms and privacy policies, such as the Microsoft Services Agreement at (aka.ms/msa). You can view these terms and policies by looking at the service terms of use or the app's settings, as applicable; please read them. The services may not be available in all regions.
 - (ii) The manufacturer or installer may also preinstall apps, which will be subject to separate license terms.
 - (iii) The software may include third party software such as Adobe Flash Player that is licensed under its own terms. You agree that your use of Adobe Flash Player is governed by the license terms for Adobe Systems Incorporated at (aka.ms/adobeflash). Adobe and Flash are either registered trademarks or

trademarks of Adobe Systems Incorporated in the United States and/or other countries.

- (iv) The software may include third party programs that are licensed to you under this agreement, or under their own terms. License terms, notices and acknowledgements, if any, for the third party program can be view at (aka.ms/thirdpartynotices).

2. Installation and Use Rights.

- a. **License.** The software license is permanently assigned to the device with which you acquired the software. You may only use the software on that device.
- b. **Device.** In this agreement, “device” means a physical hardware system) with an internal storage device capable of running the software. A hardware partition or blade is considered to be a device.
- c. **Restrictions.** The manufacturer or installer and Microsoft reserve all rights (such as rights under intellectual property laws) not expressly granted in this agreement. For example, this license does not give you any right to, and you may not:
 - (i) use or virtualize features of the software separately;
 - (ii) publish, copy (other than the permitted backup copy), rent, lease, or lend the software;
 - (iii) transfer the software (except as permitted by this agreement);
 - (iv) work around any technical restrictions or limitations in the software;
 - (v) use the software as server software, for commercial hosting, make the software available for simultaneous use by multiple users over a network, install the software on a server and allow users to access it remotely, or install the software on a device for use only by remote users;
 - (vi) reverse engineer, decompile, or disassemble the software, or attempt to do so, except and only to the extent that the foregoing restriction is (a) permitted by applicable law; (b) permitted by licensing terms governing the use of open source components that may be included with the software; or (c) required to debug changes to any libraries licensed under the GNU Lesser General Public License which are included with and linked to by the software; and
 - (vii) when using Internet-based features you may not use those features in any way that could interfere with anyone else’s use of them, or to try to gain access to or use any service, data, account, or network, in an unauthorized manner.
- d. **Multi use scenarios.**
 - (i) **Multiple versions.** If when acquiring the software, you were provided with multiple versions (such as 32-bit and 64-bit versions), you may install and activate only one of those versions at a time.
 - (ii) **Multiple or pooled connections.** Hardware or software you use to multiplex or pool connections, or reduce the number of devices or users that access or use the software, does not reduce the number of licenses you need. You may only use such hardware or software if you have a license for each instance of the software you are using.
 - (iii) **Device connections.** You may allow up to 20 other devices to access the software installed on the licensed device for the purpose of using the following software features: file services, print services, Internet information services, and Internet connection sharing and telephony services on the licensed device. The 20 connection limit applies to devices that access the software indirectly through “multiplexing” or other software or hardware that pools connections. You may allow any number of devices to access the software on the licensed device to synchronize data between devices. This section does not mean, however, that you have the right to install the software, or use the primary function of the software (other than the features listed in this section), on any of these other devices.
 - (iv) **Remote access.** Users may access the licensed device from another device using remote access

technologies, but only on devices separately licensed to run the same or higher edition of this software.

- (v) **Remote assistance.** You may use remote assistance technologies to share an active session without obtaining any additional licenses for the software. Remote assistance allows one user to connect directly to another user's computer, usually to correct problems.
- (vi) **POS application.** If the software is installed on a retail point of service device, you may use the software with a point of service application ("POS Application"). A POS Application is a software application which provides only the following functions: (i) process sales and service transactions, scan and track inventory, record and/or transmit customer information, and perform related management functions, and/or (ii) provide information directly and indirectly to customers about available products and services. You may use other programs with the software as long as the other programs: (i) directly support the manufacturer's specific use for the device, or (ii) provide system utilities, resource management, or anti-virus or similar protection. For clarification purposes, an automated teller machine ("ATM") is not a retail point of service device.
- (vii) **Cloud Computing Devices.** If your device uses Internet browsing functionality to connect to and access cloud hosted applications: (i) no desktop functions may run locally on the device, and (ii) any files that result from the use of the desktop functions may not be permanently stored on the system. "Desktop functions," as used in this agreement, means a consumer or business task or process performed by a computer or computing device. This includes but is not limited to email, word processing, spreadsheets, database, scheduling, network or internet browsing and personal finance.
- (viii) **Desktop Functions.** If your system performs desktop functions, then you must ensure that they: (i) are only used to support the application, and (ii) operate only when used with the application.

e. Specific Use. The manufacturer designed the licensed device for a specific use. You may only use the software for that use.

f. Backup copy. You may make a single copy of the software for backup purposes, and may also use that backup copy to transfer the software if it was acquired as stand-alone software, as described below.

3. Privacy; Consent to Use of Data. Your privacy is important to us. Some of the software features send or receive information when using those features. Many of these features can be switched off in the user interface, or you can choose not to use them. By accepting this agreement and using the software you agree that Microsoft may collect, use, and disclose the information as described in the Microsoft Privacy Statement available at (aka.ms/privacy), and as may be described in the user interface associated with the software features.

4. Transfer

a. Software preinstalled on device. If you acquired the software preinstalled on a device, you may transfer the license to use the software directly to another user, only with the licensed device. The transfer must include the software and, if provided with the device, an authentic Windows label including the product key. Before any permitted transfer, the other party must agree that this agreement applies to the transfer and use of the software.

b. Stand-alone software. If you acquired the software as stand-alone software, you may transfer the software to another device that belongs to you. You may also transfer the software to a device owned by someone else if (i) you are the first licensed user of the software and (ii) the new user agrees to the terms of this agreement. You may use the backup copy we allow you to make or the media that the software came on to transfer the software. Every time you transfer the software to a new device, you must remove the software from the prior device. You may not transfer the software to share licenses between devices.

5. Authorized Software and Activation. You are authorized to use this software only if you are properly licensed and the software has been properly activated with a genuine product key or by other authorized method. When you connect to the Internet while using the software, the software will automatically contact Microsoft or its affiliate

to confirm the software is genuine and the license is associated with the licensed device. You can also activate the software manually by Internet or telephone. In either case, transmission of certain information will occur, and Internet, telephone and SMS service charges may apply. During activation (or reactivation that may be triggered by changes to your device's components), the software may determine that the installed instance of the software is counterfeit, improperly licensed or includes unauthorized changes. If activation fails the software will attempt to repair itself by replacing any tampered Microsoft software with genuine Microsoft software. You may also receive reminders to obtain a proper license for the software. Successful activation does not confirm that the software is genuine or properly licensed. You may not bypass or circumvent activation. To help determine if your software is genuine and whether you are properly licensed, see (aka.ms/genuine). Certain updates, support, and other services might only be offered to users of genuine Microsoft software.

6. **Updates.** You may obtain updates only from Microsoft or authorized sources, and Microsoft may need to update your system to provide you with those updates. The software periodically checks for system and app updates, and may download and install them for you. To the extent automatic updates are enabled on your device, by accepting this agreement, you agree to receive these types of automatic updates without any additional notice.
7. **Geographic and Export Restrictions.** If your software is restricted for use in a particular geographic region, then you may activate the software only in that region. You must also comply with all domestic and international export laws and regulations that apply to the software, which include restrictions on destinations, end users, and end use. For further information on geographic and export restrictions, visit (aka.ms/georestrict) and (aka.ms/exporting).
8. **Support and Refund Procedures.** For the software generally, contact the device manufacturer or installer for support options. Refer to the support number provided with the software. For updates and supplements obtained directly from Microsoft, Microsoft may provide limited support services for properly licensed software as described at (aka.ms/mssupport). If you are seeking a refund, contact the manufacturer or installer to determine its refund policies. You must comply with those policies, which might require you to return the software with the entire device on which the software is installed for a refund.
9. **Binding Arbitration and Class Action Waiver if You Live in (or if a Business Your Principal Place of Business is in) the United States.**

We hope we never have a dispute, but if we do, you and we agree to try for 60 days to resolve it informally. If we can't, you and we agree to **binding individual arbitration before the American Arbitration Association ("AAA") under the Federal Arbitration Act ("FAA"), and not to sue in court in front of a judge or jury.** Instead, a neutral arbitrator will decide and the arbitrator's decision will be final except for a limited right of appeal under the FAA. **Class action lawsuits, class-wide arbitrations, private attorney-general actions, and any other proceeding where someone acts in a representative capacity aren't allowed. Nor is combining individual proceedings without the consent of all parties.** "We," "our," and "us" includes Microsoft, the device manufacturer, and software installer.

- a. **Disputes covered—everything except IP.** The term "dispute" is as broad as it can be. It includes any claim or controversy between you and the manufacturer or installer, or you and Microsoft, concerning the software, its price, or this agreement, under any legal theory including contract, warranty, tort, statute, or regulation, **except disputes relating to the enforcement or validity of your, your licensors', our, or our licensors' intellectual property rights.**
- b. **Mail a Notice of Dispute first.** If you have a dispute and our customer service representatives can't resolve it, send a Notice of Dispute by U.S. Mail to the manufacturer or installer, ATTN: LEGAL DEPARTMENT. If your dispute is with Microsoft, mail it to Microsoft Corporation, ATTN: LCA ARBITRATION, One Microsoft Way, Redmond, WA 98052-6399. Tell us your name, address, how to contact you, what the problem is, and what you want. A form is available at (aka.ms/disputeform). We'll do the same if we have a dispute with you. After 60 days, you or we may start an arbitration if the dispute is unresolved.
- c. **Small claims court option.** Instead of mailing a Notice of Dispute, and if you meet the court's requirements, you may sue us in small claims court in your county of residence (or if a business your principal place of business) or our principal place of business—King County, Washington USA if your dispute is with Microsoft.

We hope you'll mail a Notice of Dispute and give us 60 days to try to work it out, but you don't have to before going to small claims court.

- d. **Arbitration procedure.** The AAA will conduct any arbitration under its Commercial Arbitration Rules (or if you are an individual and use the software for personal or household use, or if the value of the dispute is \$75,000 USD or less whether or not you are an individual or how you use the software, its Consumer Arbitration Rules). For more information, see (aka.ms/adr) or call 1-800-778-7879. To start an arbitration, submit the form available at (aka.ms/arbitration) to the AAA; mail a copy to the manufacturer or installer (or to Microsoft if your dispute is with Microsoft). In a dispute involving \$25,000 USD or less, any hearing will be telephonic unless the arbitrator finds good cause to hold an in-person hearing instead. Any in-person hearing will take place in your county of residence (of if a business your principal place of business) or our principal place of business—King County, Washington if your dispute is with Microsoft. You choose. The arbitrator may award the same damages to you individually as a court could. The arbitrator may award declaratory or injunctive relief only to you individually to satisfy your individual claim.
 - e. **Arbitration fees and payments.**
 - (i) **Disputes involving \$75,000 USD or less.** The manufacturer or installer (or Microsoft if your dispute is with Microsoft) will promptly reimburse your filing fees and pay the AAA's and arbitrator's fees and expenses. If you reject our last written settlement offer made before the arbitrator was appointed, your dispute goes all the way to an arbitrator's decision (called an "award"), and the arbitrator awards you more than this last written offer, the manufacturer or installer (or Microsoft if your dispute is with Microsoft) will: (1) pay the greater of the award or \$1,000 USD; (2) pay your reasonable attorney's fees, if any; and (3) reimburse any expenses (including expert witness fees and costs) that your attorney reasonably accrues for investigating, preparing, and pursuing your claim in arbitration. The arbitrator will determine the amounts unless you and we agree on them.
 - (ii) **Disputes involving more than \$75,000 USD.** The AAA rules will govern payment of filing fees and the AAA's and arbitrator's fees and expenses.
 - (iii) **Disputes involving any amount.** If you start an arbitration we won't seek our AAA or arbitrator's fees and expenses, or your filing fees we reimbursed, unless the arbitrator finds the arbitration frivolous or brought for an improper purpose. If we start an arbitration we will pay all filing, AAA, and arbitrator's fees and expenses. We won't seek our attorney's fees or expenses from you in any arbitration. Fees and expenses are not counted in determining how much a dispute involves.
 - f. **Must file within one year.** You and we must file in small claims court or arbitration any claim or dispute (except intellectual property disputes — see Section 9.a.) within one year from when it first could be filed. Otherwise, it's permanently barred.
 - g. **Severability.** If the class action waiver is found to be illegal or unenforceable as to all or some parts of a dispute, those parts won't be arbitrated but will proceed in court, with the rest proceeding in arbitration. If any other provision of Section 9 is found to be illegal or unenforceable, that provision will be severed but the rest of Section 9 still applies.
 - h. **Conflict with AAA rules.** This agreement governs if it conflicts with the AAA's Commercial Arbitration Rules or Consumer Arbitration Rules.
 - i. **Microsoft as party or third-party beneficiary.** If Microsoft is the device manufacturer or if you acquired the software from a retailer, Microsoft is a party to this agreement. Otherwise, Microsoft is not a party but is a third-party beneficiary of your agreement with the manufacturer or installer to resolve disputes through informal negotiation and arbitration.
10. **Governing Law.** The laws of the state or country where you live (or if a business where your principal place of business is located) govern all claims and disputes concerning the software, its price, or this agreement, including breach of contract claims and claims under state consumer protection laws, unfair competition laws, implied warranty laws, for unjust enrichment, and in tort, regardless of conflict of law principles. In the United States, the

FAA governs all provisions relating to arbitration.

11. Consumer Rights, Regional Variations. This agreement describes certain legal rights. You may have other rights, including consumer rights, under the laws of your state or country. You may also have rights with respect to the party from which you acquired the software. This agreement does not change those other rights if the laws of your state or country do not permit it to do so. For example, if you acquired the software in one of the below regions, or mandatory country law applies, then the following provisions apply to you:

a. Australia. References to “Limited Warranty” are references to the express warranty provided by Microsoft or the manufacturer or installer. This warranty is given in addition to other rights and remedies you may have under law, including your rights and remedies in accordance with the statutory guarantees under the Australian Consumer Law.

In this section, “goods” refers to the software for which Microsoft or the manufacturer or installer provides the express warranty. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

b. Canada. You may stop receiving updates on your device by turning off Internet access. If and when you re-connect to the Internet, the software will resume checking for and installing updates.

c. European Union. The academic use restriction in Section 12.d(i) below does not apply in the jurisdictions listed on this site: (aka.ms/academicuse).

d. Germany and Austria.

(i) **Warranty.** The properly licensed software will perform substantially as described in any Microsoft materials that accompany the software. However, the manufacturer or installer, and Microsoft, give no contractual guarantee in relation to the licensed software.

(ii) **Limitation of Liability.** In case of intentional conduct, gross negligence, claims based on the Product Liability Act, as well as, in case of death or personal or physical injury, the manufacturer or installer, or Microsoft is liable according to the statutory law.

Subject to the preceding sentence, the manufacturer or installer, or Microsoft will only be liable for slight negligence if the manufacturer or installer or Microsoft is in breach of such material contractual obligations, the fulfillment of which facilitate the due performance of this agreement, the breach of which would endanger the purpose of this agreement and the compliance with which a party may constantly trust in (so-called “cardinal obligations”). In other cases of slight negligence, the manufacturer or installer or Microsoft will not be liable for slight negligence.

e. Other regions. See (aka.ms/variations) for a current list of regional variations

12. Additional Notices.

a. Networks, data and Internet usage. Some features of the software and services accessed through the software may require your device to access the Internet. Your access and usage (including charges) may be subject to the terms of your cellular or internet provider agreement. Certain features of the software may help you access the Internet more efficiently, but the software’s usage calculations may be different from your service provider’s measurements. You are always responsible for (i) understanding and complying with the terms of your own plans and agreements, and (ii) any issues arising from using or accessing networks, including public/open networks. You may use the software to connect to networks, and to share access information about those networks, only if you have permission to do so.

b. H.264/AVC and MPEG-4 visual standards and VC-1 video standards. The software may include H.264/MPEG-4 AVC and/or VC-1 decoding technology. MPEG LA, L.L.C. requires this notice:

THIS PRODUCT IS LICENSED UNDER THE AVC, THE VC-1, AND THE MPEG-4 PART 2 VISUAL PATENT PORTFOLIO LICENSES FOR THE PERSONAL AND NON-COMMERCIAL USE OF A CONSUMER TO (i) ENCODE VIDEO IN COMPLIANCE WITH THE ABOVE STANDARDS (“VIDEO STANDARDS”) AND/OR (ii) DECODE AVC, VC-1, AND MPEG-4 PART 2 VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL AND NON-COMMERCIAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED TO PROVIDE SUCH VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION MAY BE OBTAINED FROM MPEG LA, L.L.C. SEE WWW.MPEGLA.COM

- c. **Malware protection.** Microsoft cares about protecting your device from malware. The software will turn on malware protection if other protection is not installed or has expired. To do so, other antimalware software will be disabled or may have to be removed.
- d. **Limited rights versions.** If the software version you acquired is marked or otherwise intended for a specific or limited use, then you may only use it as specified. You may use other programs with the software as long as the other programs directly support the manufacturer’s specific use for the device, or provide system utilities, resource management, or anti-virus or similar protection.
 - (i) **Academic.** For academic use, you must be a student, faculty or staff of an educational institution at the time of purchase.
 - (ii) **Evaluation.** For evaluation (or test or demonstration) use, you may not sell the software, use it in a live operating environment, or use it after the evaluation period. Notwithstanding anything to the contrary in this Agreement, evaluation software is provided “AS IS”.
 - (iii) **NFR.** You may not sell software marked as “NFR” or “Not for Resale”.

13. **Entire Agreement.** This agreement (together with the printed paper license terms or other terms accompanying any software supplements, updates, and services that are provided by the manufacturer or installer, or Microsoft, and that you use), and the terms contained in web links listed in this agreement, are the entire agreement for the software and any such supplements, updates, and services (unless the manufacturer or installer, or Microsoft, provides other terms with such supplements, updates, or services). You can review this agreement after your software is running by going to aka.ms/useterms or going to Settings - System - About within the software. You can also review the terms at any of the links in this agreement by typing the URLs into a browser address bar, and you agree to do so. You agree that you will read the terms before using the software or services, including any linked terms. You understand that by using the software and services, you ratify this agreement and the linked terms. There are also informational links in this agreement. The links containing notices and binding terms are:

- [Windows 10 Privacy Statement \(aka.ms/privacy\)](http://aka.ms/privacy)
- [Microsoft Services Agreement \(aka.ms/msa\)](http://aka.ms/msa)
- [Adobe Flash Player License Terms \(aka.ms/adobeflash\)](http://aka.ms/adobeflash)

NO WARRANTY

THE SOFTWARE ON YOUR DEVICE (INCLUDING THE APPS) IS LICENSED "AS IS." TO THE MAXIMUM EXTENT PERMITTED BY YOUR LOCAL LAWS, YOU BEAR THE ENTIRE RISK AS TO THE SOFTWARE'S QUALITY AND PERFORMANCE. SHOULD IT PROVE DEFECTIVE, YOU ASSUME THE ENTIRE COST OF ALL SERVICING OR REPAIR. NEITHER THE DEVICE MANUFACTURER NOR MICROSOFT GIVES ANY EXPRESS WARRANTIES, GUARANTEES, OR CONDITIONS FOR THE SOFTWARE. TO THE EXTENT PERMITTED UNDER YOUR LOCAL LAWS, THE MANUFACTURER AND MICROSOFT EXCLUDE ALL IMPLIED WARRANTIES AND CONDITIONS, INCLUDING THOSE OF MERCHANTABILITY, QUALITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT. YOU MAY HAVE ADDITIONAL CONSUMER RIGHTS OR STATUTORY GUARANTEES UNDER LOCAL LAWS THAT THESE TERMS CANNOT CHANGE.

IF YOUR LOCAL LAWS IMPOSE A WARRANTY, GUARANTEE, OR CONDITION EVEN THOUGH THIS AGREEMENT DOES NOT, ITS TERM IS LIMITED TO 90 DAYS FROM WHEN THE FIRST USER ACQUIRES THE SOFTWARE. IF THE MANUFACTURER OR MICROSOFT BREACHES SUCH A WARRANTY, GUARANTEE, OR CONDITION, YOUR SOLE REMEDY, AT THE MANUFACTURER'S OR MICROSOFT'S ELECTION, IS (I) REPAIR OR REPLACEMENT OF THE SOFTWARE AT NO CHARGE, OR (II) RETURN OF THE SOFTWARE (OR AT ITS ELECTION THE DEVICE ON WHICH THE SOFTWARE WAS INSTALLED) FOR A REFUND OF THE AMOUNT PAID, IF ANY. THESE ARE YOUR ONLY REMEDIES FOR BREACH OF A WARRANTY, GUARANTEE, OR CONDITION YOUR LOCAL LAWS IMPOSE.

TO THE EXTENT NOT PROHIBITED BY YOUR LOCAL LAWS, IF YOU HAVE ANY BASIS FOR RECOVERING DAMAGES, YOU CAN RECOVER FROM THE MANUFACTURER OR MICROSOFT ONLY DIRECT DAMAGES UP TO THE AMOUNT YOU PAID FOR THE SOFTWARE (OR UP TO \$50 USD IF YOU ACQUIRED THE SOFTWARE FOR NO CHARGE). YOU WILL NOT, AND WAIVE ANY RIGHT TO, SEEK TO RECOVER ANY OTHER DAMAGES OR REMEDY, INCLUDING LOST PROFITS AND DIRECT, CONSEQUENTIAL, SPECIAL, INDIRECT, OR INCIDENTAL DAMAGES, UNDER ANY PART OF THIS AGREEMENT OR UNDER ANY THEORY. THIS LIMITATION APPLIES TO (I) ANYTHING RELATED TO THIS AGREEMENT, THE SOFTWARE (INCLUDING THE APPS), THE DEVICE, SERVICES, CORRUPTION OR LOSS OF DATA, FAILURE TO TRANSMIT OR RECEIVE DATA, CONTENT (INCLUDING CODE) ON THIRD PARTY INTERNET SITES OR THIRD PARTY PROGRAMS, AND (II) CLAIMS FOR BREACH OF CONTRACT, WARRANTY, GUARANTEE, OR CONDITION; STRICT LIABILITY, NEGLIGENCE, OR OTHER TORT; VIOLATION OF A STATUTE OR REGULATION; UNJUST ENRICHMENT; OR UNDER ANY OTHER THEORY.

THE DAMAGE EXCLUSIONS AND REMEDY LIMITATIONS IN THIS AGREEMENT APPLY EVEN IF YOU HAVE NO REMEDY (THE SOFTWARE IS LICENSED "AS IS"), IF REPAIR, REPLACEMENT, OR A REFUND (IF REQUIRED BY YOUR LOCAL LAW) DOES NOT FULLY COMPENSATE YOU FOR ANY LOSSES, IF THE MANUFACTURER OR MICROSOFT KNEW OR SHOULD HAVE KNOWN ABOUT THE POSSIBILITY OF THE DAMAGES, OR IF THE REMEDY FAILS OF ITS ESSENTIAL PURPOSE.

Check with your device manufacturer to determine if your device is covered by a warranty.

This software uses fonts produced by Fontworks Inc.
Fontworks, and font names are trademarks or registered trademarks of
Fontworks Inc.

DynaFont is a registered trademark of DynaComware Taiwan Inc.
The typefaces included herein are developed by DynaComware.

The fonts and typefaces used in this products, "Kanteiryu" are licensed by
Morisawa Inc. and the intellectual properties of those fonts and typefaces are
held by the licensor. "Kanteiryu" are trademarks of Morisawa Inc.

YOONDESIGN GROUP INC
Font Design by YoonDesign Inc.

Monotype? Monotype is a trademark of Monotype Imaging Inc. registered in the
U.S. Patent & Trademark Office and may be registered in certain other
jurisdictions.

Dom is a trademark of The Monotype Corporation and may be registered in
certain jurisdictions.

Copyright 1990-2003 Bitstream Inc. All rights reserved.

* 1. Redistributions of source code must retain the above copyright
* notice, this list of conditions and the following disclaimer.

*

* 2. Redistributions in binary form must reproduce the above copyright
* notice, this list of conditions and the following disclaimer in
* the documentation and/or other materials provided with the
* distribution.

*

* 3. All advertising materials mentioning features or use of this
* software must display the following acknowledgment:
* "This product includes software developed by the OpenSSL Project
* for use in the OpenSSL Toolkit. (<http://www.openssl.org/>)"

*

* 4. The names "OpenSSL Toolkit" and "OpenSSL Project" must not be used to
* endorse or promote products derived from this software without
* prior written permission. For written permission, please contact
* openssl-core@openssl.org.

*

* 5. Products derived from this software may not be called "OpenSSL"
* nor may "OpenSSL" appear in their names without prior written
* permission of the OpenSSL Project.

*

* 6. Redistributions of any form whatsoever must retain the following
* acknowledgment:
* "This product includes software developed by the OpenSSL Project
* for use in the OpenSSL Toolkit (<http://www.openssl.org/>)"

*

* THIS SOFTWARE IS PROVIDED BY THE OpenSSL PROJECT "AS IS" AND ANY
* EXPRESSED OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE
* IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR
* PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE OpenSSL PROJECT OR
* ITS CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL,
* SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT
* NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES;
* LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION)
* HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT,
* STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE)
* ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED
* OF THE POSSIBILITY OF SUCH DAMAGE.

* =====

*

* This product includes cryptographic software written by Eric Young
* (eyay@cryptsoft.com). This product includes software written by Tim
* Hudson (tjh@cryptsoft.com).

*

*/

```
/* Copyright (C) 1995-1998 Eric Young (eay@cryptsoft.com)
 * All rights reserved.
 *
 * This package is an SSL implementation written
 * by Eric Young (eay@cryptsoft.com).
 * The implementation was written so as to conform with Netscapes SSL.
 *
 * This library is free for commercial and non-commercial use as long as
 * the following conditions are aheared to. The following conditions
 * apply to all code found in this distribution, be it the RC4, RSA,
 * lhash, DES, etc., code; not just the SSL code. The SSL documentation
 * included with this distribution is covered by the same copyright terms
 * except that the holder is Tim Hudson (tjh@cryptsoft.com).
 *
 * Copyright remains Eric Young's, and as such any Copyright notices in
 * the code are not to be removed.
 * If this package is used in a product, Eric Young should be given attribution
 * as the author of the parts of the library used.
 * This can be in the form of a textual message at program startup or
 * in documentation (online or textual) provided with the package.
 *
 * Redistribution and use in source and binary forms, with or without
 * modification, are permitted provided that the following conditions
 * are met:
 * 1. Redistributions of source code must retain the copyright
 * notice, this list of conditions and the following disclaimer.
 * 2. Redistributions in binary form must reproduce the above copyright
 * notice, this list of conditions and the following disclaimer in the
 * documentation and/or other materials provided with the distribution.
 * 3. All advertising materials mentioning features or use of this software
 * must display the following acknowledgement:
 * "This product includes cryptographic software written by
 * Eric Young (eay@cryptsoft.com)"
 * The word 'cryptographic' can be left out if the rouines from the library
 * being used are not cryptographic related :-).
 * 4. If you include any Windows specific code (or a derivative thereof) from
 * the apps directory (application code) you must include an acknowledgement:
 * "This product includes software written by Tim Hudson (tjh@cryptsoft.com)"
 *
 * THIS SOFTWARE IS PROVIDED BY ERIC YOUNG ``AS IS" AND
 * ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE
 * IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE
 * ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE
 * FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL
```

* DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS
* OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION)
* HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT
* LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY
* OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF
* SUCH DAMAGE.

*

* The licence and distribution terms for any publically available version or
* derivative of this code cannot be changed. i.e. this code cannot simply be
* copied and put under another distribution licence
* [including the GNU Public Licence.]

*/

ThePhD/sol2

Copyright (c) 2013-2018 Rapptz, ThePhD and contributors

Permission is hereby granted, free of charge, to any person obtaining
a copy of this software and associated documentation files (the
"Software"), to deal in the Software without restriction, including
without limitation the rights to use, copy, modify, merge, publish,
distribute, sublicense, and/or sell copies of the Software, and to
permit persons to whom the Software is furnished to do so, subject to
the following conditions:

The above copyright notice and this permission notice shall be
included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND,
EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF
MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT.
IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY
CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT,
TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE
SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Copyright

This product uses the following third party software with approval. Please see below for licensing conditions:

CA certificates extracted from Mozilla

Copyright(c) 2021 Mozilla

Licensed under Mozilla Public License 2.0

(<https://opensource.org/licenses/MPL-2.0>)

*Source code available at: <https://curl.se/docs/caextract.html>

The PEM file is only a converted version of the original one and thus it is licensed under the same license as the Mozilla source file: MPL 2.0

Mozilla Public License

Version 2.0

1. Definitions

1.1. "Contributor"

means each individual or legal entity that creates, contributes to the creation of, or owns Covered Software.

1.2. "Contributor Version"

means the combination of the Contributions of others (if any) used by a Contributor and that particular Contributor's Contribution.

1.3. "Contribution"

means Covered Software of a particular Contributor.

1.4. "Covered Software"

means Source Code Form to which the initial Contributor has attached the notice in Exhibit A, the Executable Form of such Source Code Form, and Modifications of such Source Code Form, in each case including portions thereof.

1.5. "Incompatible With Secondary Licenses"

means

that the initial Contributor has attached the notice described in Exhibit B to the Covered Software; or

that the Covered Software was made available under the terms of version 1.1 or earlier of the License, but not also under the terms of a Secondary License.

1.6. "Executable Form"

means any form of the work other than Source Code Form.

1.7. "Larger Work"

means a work that combines Covered Software with other material, in a separate

file or files, that is not Covered Software.

1.8. “License”

means this document.

1.9. “Licensable”

means having the right to grant, to the maximum extent possible, whether at the time of the initial grant or subsequently, any and all of the rights conveyed by this License.

1.10. “Modifications”

means any of the following:

any file in Source Code Form that results from an addition to, deletion from, or modification of the contents of Covered Software; or

any new file in Source Code Form that contains any Covered Software.

1.11. “Patent Claims” of a Contributor

means any patent claim(s), including without limitation, method, process, and apparatus claims, in any patent Licensable by such Contributor that would be infringed, but for the grant of the License, by the making, using, selling, offering for sale, having made, import, or transfer of either its Contributions or its Contributor Version.

1.12. “Secondary License”

means either the GNU General Public License, Version 2.0, the GNU Lesser General Public License, Version 2.1, the GNU Affero General Public License, Version 3.0, or any later versions of those licenses.

1.13. “Source Code Form”

means the form of the work preferred for making modifications.

1.14. “You” (or “Your”)

means an individual or a legal entity exercising rights under this License. For legal entities, “You” includes any entity that controls, is controlled by, or is under common control with You. For purposes of this definition, “control” means (a) the power, direct or indirect, to cause the direction or management of such entity, whether by contract or otherwise, or (b) ownership of more than fifty percent (50%) of the outstanding shares or beneficial ownership of such entity.

2. License Grants and Conditions

2.1. Grants

Each Contributor hereby grants You a world-wide, royalty-free, non-exclusive license:

under intellectual property rights (other than patent or trademark) Licensable by

such Contributor to use, reproduce, make available, modify, display, perform, distribute, and otherwise exploit its Contributions, either on an unmodified basis, with Modifications, or as part of a Larger Work; and under Patent Claims of such Contributor to make, use, sell, offer for sale, have made, import, and otherwise transfer either its Contributions or its Contributor Version.

2.2. Effective Date

The licenses granted in Section 2.1 with respect to any Contribution become effective for each Contribution on the date the Contributor first distributes such Contribution.

2.3. Limitations on Grant Scope

The licenses granted in this Section 2 are the only rights granted under this License. No additional rights or licenses will be implied from the distribution or licensing of Covered Software under this License. Notwithstanding Section 2.1(b) above, no patent license is granted by a Contributor:

for any code that a Contributor has removed from Covered Software; or

for infringements caused by: (i) Your and any other third party's modifications of Covered Software, or (ii) the combination of its Contributions with other software (except as part of its Contributor Version); or

under Patent Claims infringed by Covered Software in the absence of its Contributions.

This License does not grant any rights in the trademarks, service marks, or logos of any Contributor (except as may be necessary to comply with the notice requirements in Section 3.4).

2.4. Subsequent Licenses

No Contributor makes additional grants as a result of Your choice to distribute the Covered Software under a subsequent version of this License (see Section 10.2) or under the terms of a Secondary License (if permitted under the terms of Section 3.3).

2.5. Representation

Each Contributor represents that the Contributor believes its Contributions are its original creation(s) or it has sufficient rights to grant the rights to its Contributions conveyed by this License.

2.6. Fair Use

This License is not intended to limit any rights You have under applicable copyright doctrines of fair use, fair dealing, or other equivalents.

2.7. Conditions

Sections 3.1, 3.2, 3.3, and 3.4 are conditions of the licenses granted in Section 2.1.

3. Responsibilities

3.1. Distribution of Source Form

All distribution of Covered Software in Source Code Form, including any Modifications that You create or to which You contribute, must be under the terms of this License. You must inform recipients that the Source Code Form of the Covered Software is governed by the terms of this License, and how they can obtain a copy of this License. You may not attempt to alter or restrict the recipients' rights in the Source Code Form.

3.2. Distribution of Executable Form

If You distribute Covered Software in Executable Form then:

such Covered Software must also be made available in Source Code Form, as described in Section 3.1, and You must inform recipients of the Executable Form how they can obtain a copy of such Source Code Form by reasonable means in a timely manner, at a charge no more than the cost of distribution to the recipient; and

You may distribute such Executable Form under the terms of this License, or sublicense it under different terms, provided that the license for the Executable Form does not attempt to limit or alter the recipients' rights in the Source Code Form under this License.

3.3. Distribution of a Larger Work

You may create and distribute a Larger Work under terms of Your choice, provided that You also comply with the requirements of this License for the Covered Software. If the Larger Work is a combination of Covered Software with a work governed by one or more Secondary Licenses, and the Covered Software is not Incompatible With Secondary Licenses, this License permits You to additionally distribute such Covered Software under the terms of such Secondary License(s), so that the recipient of the Larger Work may, at their option, further distribute the Covered Software under the terms of either this License or such Secondary License(s).

3.4. Notices

You may not remove or alter the substance of any license notices (including copyright notices, patent notices, disclaimers of warranty, or limitations of liability) contained within the Source Code Form of the Covered Software, except that You may alter any license notices to the extent required to remedy known factual

inaccuracies.

3.5. Application of Additional Terms

You may choose to offer, and to charge a fee for, warranty, support, indemnity or liability obligations to one or more recipients of Covered Software. However, You may do so only on Your own behalf, and not on behalf of any Contributor. You must make it absolutely clear that any such warranty, support, indemnity, or liability obligation is offered by You alone, and You hereby agree to indemnify every Contributor for any liability incurred by such Contributor as a result of warranty, support, indemnity or liability terms You offer. You may include additional disclaimers of warranty and limitations of liability specific to any jurisdiction.

4. Inability to Comply Due to Statute or Regulation

If it is impossible for You to comply with any of the terms of this License with respect to some or all of the Covered Software due to statute, judicial order, or regulation then You must: (a) comply with the terms of this License to the maximum extent possible; and (b) describe the limitations and the code they affect. Such description must be placed in a text file included with all distributions of the Covered Software under this License. Except to the extent prohibited by statute or regulation, such description must be sufficiently detailed for a recipient of ordinary skill to be able to understand it.

5. Termination

5.1. The rights granted under this License will terminate automatically if You fail to comply with any of its terms. However, if You become compliant, then the rights granted under this License from a particular Contributor are reinstated (a) provisionally, unless and until such Contributor explicitly and finally terminates Your grants, and (b) on an ongoing basis, if such Contributor fails to notify You of the non-compliance by some reasonable means prior to 60 days after You have come back into compliance. Moreover, Your grants from a particular Contributor are reinstated on an ongoing basis if such Contributor notifies You of the non-compliance by some reasonable means, this is the first time You have received notice of non-compliance with this License from such Contributor, and You become compliant prior to 30 days after Your receipt of the notice.

5.2. If You initiate litigation against any entity by asserting a patent infringement claim (excluding declaratory judgment actions, counter-claims, and cross-claims) alleging that a Contributor Version directly or indirectly infringes any patent, then the rights granted to You by any and all Contributors for the Covered Software under Section 2.1 of this License shall terminate.

5.3. In the event of termination under Sections 5.1 or 5.2 above, all end user license agreements (excluding distributors and resellers) which have been validly granted by You or Your distributors under this License prior to termination shall survive termination.

6. Disclaimer of Warranty

Covered Software is provided under this License on an “as is” basis, without warranty of any kind, either expressed, implied, or statutory, including, without limitation, warranties that the Covered Software is free of defects, merchantable, fit for a particular purpose or non-infringing. The entire risk as to the quality and performance of the Covered Software is with You. Should any Covered Software prove defective in any respect, You (not any Contributor) assume the cost of any necessary servicing, repair, or correction. This disclaimer of warranty constitutes an essential part of this License. No use of any Covered Software is authorized under this License except under this disclaimer.

7. Limitation of Liability

Under no circumstances and under no legal theory, whether tort (including negligence), contract, or otherwise, shall any Contributor, or anyone who distributes Covered Software as permitted above, be liable to You for any direct, indirect, special, incidental, or consequential damages of any character including, without limitation, damages for lost profits, loss of goodwill, work stoppage, computer failure or malfunction, or any and all other commercial damages or losses, even if such party shall have been informed of the possibility of such damages. This limitation of liability shall not apply to liability for death or personal injury resulting from such party’s negligence to the extent applicable law prohibits such limitation. Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so this exclusion and limitation may not apply to You.

8. Litigation

Any litigation relating to this License may be brought only in the courts of a jurisdiction where the defendant maintains its principal place of business and such litigation shall be governed by laws of that jurisdiction, without reference to its conflict-of-law provisions. Nothing in this Section shall prevent a party’s ability to bring cross-claims or counter-claims.

9. Miscellaneous

This License represents the complete agreement concerning the subject matter hereof.

If any provision of this License is held to be unenforceable, such provision shall be

reformed only to the extent necessary to make it enforceable. Any law or regulation which provides that the language of a contract shall be construed against the drafter shall not be used to construe this License against a Contributor.

10. Versions of the License

10.1. New Versions

Mozilla Foundation is the license steward. Except as provided in Section 10.3, no one other than the license steward has the right to modify or publish new versions of this License. Each version will be given a distinguishing version number.

10.2. Effect of New Versions

You may distribute the Covered Software under the terms of the version of the License under which You originally received the Covered Software, or under the terms of any subsequent version published by the license steward.

10.3. Modified Versions

If you create software not governed by this License, and you want to create a new license for such software, you may create and use a modified version of this License if you rename the license and remove any references to the name of the license steward (except to note that such modified license differs from this License).

10.4. Distributing Source Code Form that is Incompatible With Secondary Licenses

If You choose to distribute Source Code Form that is Incompatible With Secondary Licenses under the terms of this version of the License, the notice described in Exhibit B of this License must be attached.

Exhibit A - Source Code Form License Notice

This Source Code Form is subject to the terms of the Mozilla Public License, v. 2.0. If a copy of the MPL was not distributed with this file, You can obtain one at <https://mozilla.org/MPL/2.0/>.

If it is not possible or desirable to put the notice in a particular file, then You may include the notice in a location (such as a LICENSE file in a relevant directory) where a recipient would be likely to look for such a notice.

You may add additional accurate notices of copyright ownership.

Exhibit B - "Incompatible With Secondary Licenses" Notice

This Source Code Form is "Incompatible With Secondary Licenses" , as defined by the Mozilla Public License, v. 2.0.

libcurl

The curl license

COPYRIGHT AND PERMISSION NOTICE

Copyright (c) 1996 - 2022, Daniel Stenberg, daniel@haxx.se, and many contributors, see the THANKS file.

All rights reserved.

Permission to use, copy, modify, and distribute this software for any purpose with or without fee is hereby granted, provided that the above copyright notice and this permission notice appear in all copies.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OF THIRD PARTY RIGHTS.

IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Except as contained in this notice, the name of a copyright holder shall not be used in advertising or otherwise to promote the sale, use or other dealings in this Software without prior written authorization of the copyright holder.

Part number: TNT45-24177-00

Nov. 2024

BANDAI NAMCO AMUSEMENT AMERICA INC
1550 Glenlake Ave.
Itasca, IL 60143

Bandai Namco Amusement Inc.